Operator's Manual

CRAFTSMAN®

6.0 Horse Power
YARD VACUUM
Model No. 247.770550



CAUTION: Before using this product, read this manual and follow all Safety Rules and Operating Instructions.

- Safety
- Assembly
- Operation
- Maintenance
- Parts
- Español

Sears, Roebuck and Co., Hoffman Estates, IL 60179, U.S.A.

Visit our Sears website: www.sears.com/craftsman

Printed in U.S.A. FORM NO. 769-00407 (7/02)

TABLE OF CONTENTS Content Page Content Page 2 Service and Adjustments Warranty 14 3 Safety Storage 16 5 Troubleshooting 17 Assembly 7 Parts List Operation 18 Maintenance 12

WARRANTY

Limited Warranty on Craftsman Yard Vacuum

For one (1) year from the date of purchase, if this Craftsman Equipment is maintained, lubricated, and tuned up according to the instructions to the operator's manual, Sears will repair or replace free of charge any parts found to be defective in material or workmanship. Warranty service is available free of charge by returning Craftsman equipment to your nearest Sears Service Center. In-home warranty service is available but a trip charge will apply. This Warranty applies only while this product is in the United States.

This Warranty does not cover:

- Expendable items which become worn during normal use, such as spark plugs, air cleaners, belts, and oil filters.
- Tire replacement or repair caused by punctures from outside objects, such as nails, thorns, stumps, or glass.
- Repairs necessary because of operator abuse, including but not limited to, damage caused by objects, such
 as stones or metal debris, oversized stock, impacting objects that bend the frame or crankshaft, or overspeeding the engine.
- Repairs necessary because of operator negligence, including but not limited to, electrical and mechanical damage caused by improper storage, failure to use the proper grade and amount of engine oil, or failure to maintain the equipment according to the instructions contained in the operator's manual.
- Engine (fuel system) cleaning or repairs caused by fuel determine to be contaminated or oxidized (stale). In general, fuel should be used **within 30 days** of its purchase date.
- Equipment used for commercial or rental purposes.

TO LOCATE THE NEAREST SEARS SERVICE CENTER OR TO SCHEDULE SERVICE, SIMPLY CONTACT SEARS AT 1-800-4-MY-HOME.

This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

PRODUCT SPECIFICATION								
6.0 Horse Power	Model Number. 247.770550							
SAE 30								
20 Ounces	Serial Number							
1 1/2 Quarts	Date of Purchase							
Champion RJ-19LM								
.030"	Record both serial number and date of purchase and							
	keep in a safe place for future reference.							
	6.0 Horse Power SAE 30 20 Ounces 1 1/2 Quarts Champion RJ-19LM							

SAFETY



WARNING: This symbol points out important safety instructions which, if not followed, could endanger the personal safety and/or property of yourself and others. Read and follow all instructions in this manual before attempting to operate this machine. Failure to comply with these instructions may result in personal injury. When you see this symbol - **heed its warning**.

WARNING: Engine Exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to State of California to cause cancer and birth defects or other reproductive harm.

DANGER: This machine was built to be operated according to the rules for safe operation in this manual. As with any type of power equipment, carelessness or error on the part of the operator can result in serious injury. This machine is capable of amputating hands and feet and throwing objects. Failure to observe the following safety instructions could result in serious injury or death.

TRAINING

- Read, understand, and follow all instructions on the machine and in the manual(s) before attempting to assemble and operate. Keep this manual in a safe place for future and regular reference and for ordering replacement parts.
- Be familiar with all controls and their proper operation. Know how to stop the machine and disengage them quickly.
- Never allow children under 16 years old to operate this machine. Children 16 years old and over should read and understand the operation instructions and safety rules in this manual and should be trained and supervised by a parent.
- 4. Never allow adults to operate this machine without proper instruction.
- Keep bystanders, helpers, pets, and children at least 75 feet from the machine while it is in operation. Stop machine if anyone enters the area.
- 6. Never run an engine indoors or in a poorly ventilated area. Engine exhaust contains carbon monoxide, an odorless and deadly gas.
- Do not put hands and feet near rotating parts or in the feeding chambers and discharge opening.
 Contact with the rotating impeller can amputate fingers, hands, and feet.
- 8. Never attempt to unclog either the feed intake or discharge opening, remove or empty vacuum bag, or inspect and repair the machine while the engine is running. Shut the engine off and wait until all moving parts have come to a complete stop. Disconnect the spark plug wire and ground it against the engine.

PREPARATION

 Thoroughly inspect the area where the equipment is to be used. Remove all rocks, bottles, cans, or other foreign objects which could be picked up or thrown and cause personal injury or damage to the machine.

- Always wear safety glasses or safety goggles during operation or while performing an adjustment or repair, to protect eyes. Thrown objects which ricochet can cause serious injury to the eyes.
- Wear sturdy, rough-soled work shoes and closefitting slacks and shirts. Loose fitting clothes or jewelry can be caught in movable parts. Never operate this machine in bare feet or sandals. Wear leather work gloves when feeding material in the chipper chute.
- Before starting, check all bolts and screws for proper tightness to be sure the machine is in safe working condition. Also, visually inspect machine for any damage at frequent intervals.
- Maintain or replace safety and instructions labels, as necessary.
- 6. To avoid personal injury or property damage use extreme care in handling gasoline. Gasoline is extremely flammable and the vapors are explosive. Serious personal injury can occur when gasoline is spilled on yourself or your clothes which can ignite. Wash your skin and change clothes immediately.
 - a. Use only an approved gasoline container.
 - b. Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
 - c. Never fuel machine indoors.
 - d. Never remove gas cap or add while the engine is hot or running.
 - e. Allow engine to cool at least two minutes before refueling.
 - f. Never over fill fuel tank. Fill tank to no more than 1/2 inch below bottom of filler neck to provide space for fuel expansion.
 - g. Replace gasoline cap and tighten securely.
 - If gasoline is spilled, wipe it off the engine and equipment. Move machine to another area. Wait 5 minutes before starting the engine.

- Never store the machine or fuel container inside where there is an open flame, spark, or pilot light (e.g. furnace, water heater, space heater, clothes dryer, etc.)
- j. To reduce a fire hazard, keep machine free of grass, leaves, or other debris build-up. Clean up oil fuel spillage and remove any fuel soaked debris.
- k. Allow machine to cool at least 5 minutes before storing.

OPERATION

- Do not put hands and feet near rotating parts or in the feeding chambers and discharge opening.
 Contact with the rotating impeller can amputate fingers, hands, and feet.
- 2. Before starting the machine, make sure the chipper chute, feed intake, and cutting chamber are empty and free of all debris.
- Thoroughly inspect all material to be shredded and remove any metal, rocks, bottles, cans, or other foreign objects which could cause personal injury or damage to the machine.
- 4. If the impeller strikes a foreign object or if your machine should start making an unusual noise or vibration, immediately shut the engine off. Allow the impeller to come to a complete stop. Disconnect the spark plug wire, ground it against the engine and perform the following steps:
 - a. Inspect for damage.
 - b. Repair or replace any damaged parts.
 - c. Check for any loose parts and tighten to assure continued safe operation.
- Do not allow an accumulation of processed material to build up in the discharge area. This can prevent proper discharge and result in kickback of material through the feed opening.
- Do not attempt to shred or chip material larger than specified on the machine or in this manual.
 Personal injury or machine damage could result.
- 7. Never attempt to unclog either the feed intake or discharge opening while the engine is running. Shut the engine off, wait until all moving parts have stopped, disconnect the spark plug wire and ground it against the engine before clearing debris.
- 8. Never operate without vacuum bag and discharge chute properly attached to the machine. Never empty or change vacuum bag while the engine is running. Zippered end of vacuum bag must be kept closed at all times during operation.

- Never operate without either the inlet nozzle or optional hose attachment properly attached to the machine. Never attempt to attach or change either attachment while the engine is running.
- 10. Keep all guards, deflectors and safety devices in place and operating properly.
- 11. Keep your face and body back and to the side of the chipper chute while feeding material into the machine to avoid accidental kickback injuries.
- 12. Never operate this machine without good visibility or light. Always be sure of your footing and keep a firm hold on the handles.
- 13. Do not operate this machine on a gravel surface.
- 14. Do not operate this machine while under the influence of alcohol or drugs.
- 15. Muffler and engine become hot and can cause a burn. Do not touch.
- 16. Never pick up or carry machine while the engine is running.

MAINTENANCE AND STORAGE

- 1. Never tamper with safety devices. Check their proper operation regularly.
- 2. Check bolts and screws for proper tightness at frequent intervals to keep the machine in safe working condition. Also, visually inspect machine for any damage and repair, if needed.
- Before cleaning, repairing, or inspecting, stop the engine and make certain the impeller and all moving parts have stopped. Disconnect the spark plug wire and ground it against the engine to prevent unintended starting.
- 4. Do not change the engine governor settings or overspeed the engine. The governor controls the maximum safe operating speed of the engine.
- 5. Maintain or replace safety and instruction labels, as necessary.
- 6. Follow this manual for safe loading, unloading, transporting, and storage of this machine.
- 7. Never store the machine or fuel container inside where there is an open flame, spark or pilot light such as a water heater, furnace, clothes dryer, etc.
- 8. Always refer to the operator's manual for proper instructions on off-season storage.
- 9. If the fuel tank has to be drained, do this outdoors.
- 10. Observe proper disposal laws and regulations for gas, oil, etc. to protect the environment.

ASSEMBLY




Figure 1

IMPORTANT: This unit is shipped **without gasoline or oil in the engine**. After assembly, see OPERATION section of this manual for proper fuel and engine oil fill-up.

NOTE: Reference to right and left hand side of the Yard Vacuum is observed from the operating position. See Figure 1.

This Yard Vacuum has been completely assembled at the factory, except for the handle, bag, and blower chute. These parts are shipped loose in the carton. A pair of safety glasses and a 20-oz. bottle of engine oil are also included in the carton. See Figure 1.

REMOVING UNIT FROM CARTON


- Cut the corners of the carton.
- · Remove all loose parts.
- Remove packing material.
- Lift unit from the rear to discard packing material from under unit and roll unit out of carton.
- Check carton thoroughly for any other loose parts.

LOOSE PARTS IN CARTON (See Figure 1)

- Handle Assembly
- Hose Assembly
- Bag
- Blower Chute
- Safety Glasses (Not Shown)
- A 20-oz. Bottle of Engine Oil (may be located in bag)
- Operator's Manual

DISCONNECTING SPARK PLUG

Before proceeding with assembly of your new Yard Vacuum, disconnect the spark plug wire from the spark plug and ground onto the retaining post on the engine. This will prevent accidental starting of the engine. See Figure 2.




. .9... -

ATTACHING THE HANDLE

 Unfold the upper handle until it aligns with lower handle. Make sure the rope guide is on the right side of upper handle. See Figure 1.

- Secure the two handles by tightening the upper wing nuts (carriage bolts must be seated properly into the handle).
- Remove the hairpin clips from the handle brackets and remove the carriage bolts and wing nuts from the lower handle. See Figure 3.
- Place the bottom holes in lower handle over the pins on handle brackets and secure with hairpin clips.
- Insert carriage bolts through upper hole in lower handle from the outside and secure with wing nuts.



- Loosen the wing nut that secures the rope guide to the right side of upper handle.
- Pull the starter rope out of the engine slowly and slip the starter rope into the rope guide. Tighten the wing nut.

Attaching The Hose Assembly

- Slide hose adapter of hose assembly into the base adapter located on the left front of the Yard Vacuum. See Figure 4.
- Pull spring loaded pin out on the base and align pin with the first hole in the hose adapter.
- Release the pin to lock the hose in place.
- Connect the hose handle near nozzle end of hose to the side bracket on the upper handle. Refer to Figure 7.




Figure 4

 Snap hose handle to the lower handle bracket to secure in place and lay hose tubing on side bracket hanger next to chipper chute. Refer to Figure 7.

ATTACHING THE BAG




Figure 5

- Grasp bag handle with one hand and slide locking rod on mounting bracket with other hand toward engine. Use the end of mounting bracket as leverage when sliding the locking rod. See Figure 5.
- Slip bag over the rim of the discharge opening and release locking rod to secure bag in place.
- Snap bag clip to the top of the lower handle.
- Place the lower straps on the bag over the top of lower handle, hooking them on the studs.

NOTE: The bag/chute switch button attached to the mounting bracket must be fully depressed by the tip of front tab on bag handle when securing the bag or engine will not start.

ATTACHING THE BLOWER CHUTE

NOTE: The bag must be removed before installing the blower chute.

- Grasp blower chute with one hand and slide locking rod on mounting bracket with other hand toward engine. Use the end of mounting bracket as leverage when sliding the locking rod. See Figure 6.
- Slip blower chute over rim of discharge opening and release locking rod to secure chute in place.

 Raise the nozzle height to the highest setting when using the blower chute. Refer to nozzle height adjustment in the ADJUSTMENT section.

NOTE: The bag/chute switch button attached to the mounting bracket must be fully depressed by the tip of front tab on the blower chute or engine will not start.




Figure 6

OPERATION

Know Your Yard Vacuum

Read this operator's manual and safety rules before operating your Yard Vacuum. Compare the illustrations below with your equipment to familiarize yourself with the location of various controls and adjustments. Save this manual for future reference.



The operation of any Yard Vacuum can result in foreign objects being thrown into the eyes, which can result in severe eye damage. **Always wear safety glasses**, provided with the Yard Vacuum, for operating this equipment or while performing any adjustments or repairs on it.




Figure 7

OPERATING CONTROLS (See Figure 7)

Chipper Chute

Allows twigs and small branches up to 1 1/2" in diameter to be fed into the impeller for chipping.

Nozzle

Yard waste such as leaves and pine needles can be vacuumed up through the nozzle for shredding.

Bag

Collects shredded material fed in through the chipper chute or vacuumed in through the nozzle.

Blower Chute

When attached to unit, the blower chute is used to blow or scatter yard waste such as leaves, pine needle, or small twigs across yard.

Bag Handle


Used to grasp bag in order to assist in attaching, removing, and emptying bag.

Nozzle Height Adjustment Lever

Used to adjust the nozzle ground clearance ranging from 5/8" to 4 1/8".

Throttle Control / Choke Lever

This single lever controls the engine speed, stop function, and the choke of the carburetor. Through four separate positions on the lever from left to right, the operation is as follows:



Primer

The primer is used to assist in cold starting an engine.

Starter Handle

Used to start the engine.

Meets ANSI safety standards

Craftsman Yard Vacuums conform to the safety standard of the American National Standards Institute (ANSI).

Hose Assembly

Used as an alternative to the nozzle to vacuum yard waste such as leaves or pine needles in hard to reach places.

Hose Handle

Used to guide hose assembly when vacuuming.


Nozzle/Hose Vac Handle

The nozzle/hose vac handle is located on top of the nozzle and it is used to regulate the vacuum between the nozzle and the hose assembly.

GAS AND OIL FILL-UP

Oil (one 20-oz. bottle shipped with unit)

Only use high quality detergent oil rated with API service classification SF, SG, or SH. Select the oil's SAE viscosity grade according to the expected operating temperature. Follow the chart below.



NOTE: Although multi-viscosity oils (5W30, 10W30, etc.) improve starting in cold weather, they will result in increased oil consumption when used above 32°F. Check your engine oil level more frequently to avoid possible engine damage from running low on oil.

- Remove oil fill dipstick.
- With the Yard Vacuum on level ground, use a funnel to fill engine with oil to FULL mark on dipstick. Capacity is approximately 20 oz. Be careful not to overfill. Overfilling will cause the engine to smoke profusely and will result in poor engine performance. The oil bottle packaged with your Yard Vacuum contains 20 oz. of oil.
- Check the oil level making certain not to rub the dipstick along the inside walls of the oil fill tube.
 This would result in a false dipstick reading. Refill to FULL mark on dipstick, if necessary. Replace dipstick and tighten.
- Check oil level three times prior to starting engine to be certain you've gotten an accurate dipstick reading. Running the engine with too little oil can result in permanent engine damage.

Gasoline

- Remove fuel cap from the fuel tank.
- Make sure the container from which you will pour the gasoline is clean and free from rust or foreign particles. Never use gasoline that may be stale from long periods of storage in its container.
 Gasoline that has been sitting for any period longer than four weeks should be considered stale.

- Fill fuel tank with clean, fresh, unleaded regular, unleaded premium or reformulated automotive gasoline only. DO NOT use Ethyl or high octane gasoline. Do not use gasoline containing METHANOL. Replace fuel cap.
- To avoid engine problems, the fuel system should be emptied before storage for 30 days or longer.
 Drain the gas tank, start the engine and let it run until the fuel lines and carburetor are empty. Use fresh fuel next season. See STORAGE section for additional information.



WARNING: Use extreme care when handling gasoline. Gasoline is extremely flammable and the vapors are explosive. Never fuel machine indoors or while the engine is hot or running. Extinguish cigarettes, cigars, pipes, and other sources of ignition.

 Check the fuel level periodically to avoid running out of gasoline while operating the Yard Vacuum.
 If the unit runs out of gas as it is chipping, it may be necessary to unclog the unit before it can be restarted. Refer to SERVICE AND ADJUSTMENT section.

TO STOP ENGINE

- Move throttle control lever to STOP or OFF position.
- Disconnect spark plug wire and ground it to the post to prevent accidental starting while the equipment is unattended.



WARNING: When moving throttle control lever, be careful of heated surfaces and sharp edges on muffler guard.

TO START ENGINE

- 1. Attach spark plug wire and rubber boot to spark plug.
- The bag/chute switch button must be fully depressed by the tip of front tab on bag handle or blower chute for engine to start.
- 3. Make sure bag/chute switch wire is connected to engine and grounded to mounting bracket.
- Gas tank should be filled 3/4 to full before starting.

5. When temperature is above 32 degrees F:

- Move throttle control / choke level to START/ RUN position.
- Depress the primer bulb firmly with your thumb three times. Wait about two seconds between each push. Do not use the primer to restart a warm engine after a short shutdown. See Figure 8.

When temperature is below 32 degrees F:

- Move throttle control / choke lever on engine to CHOKE position. (A warm engine may not require choking.) See Figure 8.
- If not using choke to start engine, move throttle control / choke lever to START/RUN position.
- Depress the primer bulb firmly with your thumb three times. Wait about two seconds between each push.

NOTE: See air cleaner on side of engine for further starting instructions.




Figure 8

- 6. Standing behind the unit, grasp starter handle and pull rope out until you feel a drag.
- 7. Pull the rope with a rapid, continuous, full arm stroke. Keep a firm grip on the starter handle. Let the rope rewind slowly.
- Repeat, if necessary, until engine starts. When engine starts, move throttle /choke lever gradually to START/RUN position.
- 9. If engine falters, move control lever to CHOKE position, then back to START/RUN position.
- 10. ALWAYS keep the throttle control in the START/ RUN position when operating the Yard Vacuum.

TO EMPTY BAG

- Unhook bag straps from the lower handle and unsnap bag clip from top of the lower handle.
 See Figure 9.
- Grasp bag handle with one hand and pull lock rod on mounting bracket with other hand toward engine to release.
- Remove bag from over the rim of the discharge opening. Refer to Figure 4.
- Twist the two buttons on the back of the bag to unlock and empty contents. See Figure 9.
- Hold bag handle and bag clip while emptying the contents.
- Compress bag opening and fold inner flap over opening.
- Fold outer flap over inner flap and insert buttons on the bag through metal outlets.
- Twist the buttons to lock bag.




Figure 9

TO REMOVE BLOWER CHUTE

- Grasp blower chute with one hand and pull lock rod on mounting bracket with other hand toward engine to release. Refer to Figure 6.
- Remove blower chute from over the rim of the discharge opening.

Using the Nozzle Vacuum

- Place nozzle/hose vac handle in the top position on the nozzle to vacuum through nozzle. See Figure 10.
- The spring loaded pin must be in the first hole of the hose adapter to operate the nozzle vac.
- Place both hands on top of upper handle to push unit over yard waste.

Yard waste such as leaves and pine needles can be vacuumed up through the nozzle for shredding. After material has been shredded by the flail blades on the impeller assembly, it will be discharged into catcher bag or through blower chute. Do not attempt to shred or chip any material other than vegetation found in a normal yard (i.e. branches, leaves, twigs, etc.) Avoid fibrous plants such as tomato vines until they are thoroughly dried out. Materials such as stalks or heavy branches up to 1 1/2" in diameter may be fed into the chipper chute.



WARNING: Do not attempt to shred, chip, or vacuum any material larger than specified on the machine or in this manual. Personal injury or damage to the machine could result.




Figure 10

IMPORTANT: The flail screen is located inside the housing in the discharge area. If the flail screen becomes clogged, remove and clean as instructed in SECTION 5: MAINTAINING YOUR YARD VACUUM. For best performance, it is also important to keep the chipper blade sharp.



WARNING: Do not at any time make any adjustments without first stopping engine and disconnecting spark plug wire.

Using the Hose Assembly

- Place nozzle/hose vac handle in the bottom position on the nozzle to redirect vacuum to the hose assembly. See Figure 11.
- The spring loaded pin must be in the second hole of the hose adapter to operate the hose assembly.
- Unhook the hose from upper handle bracket and grasp the hose handle to guide while vacuuming yard waste such as leaves or pine needles in hard to reach places.




Figure 11

Nozzle Height Adjustment

The nozzle can be adjusted to any six positions, ranging from 5/8" to 4 1/8" ground clearance. The nozzle height has to be adjusted according to the conditions. Move the height adjustment levers forward or backward to adjust the nozzle upwards or downwards. See Figure 12.

NOTE: In general, raise the nozzle height to vacuum a thick layer of leaves or to operate with the blower chute and lower the nozzle height for smoother surfaces.




Figure 12

MAINTENANCE

	AINTENANCE CHEDULE	8000	And Sp. 150	687 P. 188	Sinol Ask	COUNTY OF THE PERSON OF THE PE	Sun So do So	
PRODUCT	Lubrication				$ \sqrt{} $			
PROI	Clean equipment		\checkmark				\triangleleft	
	Check engine oil							
ш	Change engine oil							
ENGINE	Service air cleaner				\checkmark			
□	Service spark plug					\triangleleft		
	Service muffler							
	Clean engine				=		\triangleleft	

GENERAL RECOMMENDATIONS

- Always observe safety rules when performing any maintenance.
- The warranty on this Yard Vacuum does not cover items that have been subjected to operator abuse or negligence. To receive full value from the warranty, operator must maintain the equipment as instructed in this manual.
- Some adjustments will need to be made periodically to maintain your equipment properly.
- Follow the maintenance schedule.
- Periodically check all fasteners and make sure they are tight.



WARNING: Always stop the engine and disconnect and ground the spark plug wire before performing any maintenance or adjustments.

LUBRICATION

- Wheels- Place a few drops of SAE 30 oil on each shoulder screw once a season.
 Refer to Figure 7.
- Nozzle height adjustment levers- Lubricate nozzle height adjustment levers with light oil. Refer to Figure 7.
- Locking Rod- Lubricate the lock rod and compression springs which attach to the mounting bracket. Refer to Figure 5.

CLEAN EQUIPMENT

- Clean the Yard Vacuum thoroughly after each use.
- Wash the bag periodically with water. Allow to dry thoroughly in the shade.
- If the flail screen becomes clogged, remove and clean as instructed in the SERVICE AND ADJUSTMENT section.

NOTE: Cleaning with a forceful spray of water is not recommended as it could contaminate the fuel system.

CHECK ENGINE OIL

- · Remove oil fill dipstick.
- Check oil level on dipstick. Level should be at FULL mark.
- Replace dipstick and tighten.

CHANGE ENGINE OIL

- Only use high quality detergent oil rated with API service classification SF, SG, or SH. Select the oil's SAE viscosity grade according to the expected operating temperature. Refer to operation section for viscosity chart.
- Stop engine and wait several minutes before checking oil level. With engine on level ground, the oil must be to FULL mark on dipstick.
- Change engine oil after the first five hours of operation, and every twenty-five hours thereafter.

TO DRAIN OIL

Drain oil while engine is warm. Follow the instructions given below.

- Drain the gas tank, start the engine and let it run until the fuel line and carburetor are empty.
- Remove oil fill dipstick.
- Tip unit on its side to drain through the oil fill tube.
- When engine is drained of all oil, refill with approximately 20 oz. of fresh oil. Refer to Gas And Oil Fill-up in OPERATION section.
- · Replace dipstick.

SERVICE AIR CLEANER

The air cleaner prevents damaging dirt, dust, etc., from entering the carburetor and being forced into the engine and is important to engine life and performance. The air cleaner consists of a foam filter. **Never run** the engine without an air cleaner completely assembled.

To Service Air Cleaner:

- Remove foam filter from plastic housing on top of engine.
- Wash in water and detergent solution, and squeeze (do not twist) until all dirt is removed.
- Rinse thoroughly in clear water.
- Wrap in a clean cloth and squeeze (do not twist) until completely dry, or allow to air dry.
- Saturate with engine oil and squeeze to distribute oil and remove excess oil.
- · Replace foam filter in plastic housing

NOTE: If the foam filter is torn or damaged in any way, replace it.



WARNING: WARNING: Temperature of muffler and nearby areas may exceed 150° F(65°C). Avoid these areas.

SERVICE SPARK PLUG

 Clean the spark plug and reset the gap to .030" at least once a season or every 50 hours of operation. See Figure 13. Spark plug replacement is recommended at the start of each season. Refer to engine parts list for correct spark plug type.

NOTE: Do not sandblast spark plug. Spark plug should be cleaned by scraping or wire brushing and washing with a commercial solvent.




Figure 13

SERVICE MUFFLER

- Inspect muffler periodically, and replace if necessary.
- If your engine is equipped with a spark arrester screen assembly, remove after every 50 hours of use for cleaning and inspection. Replace if damaged.



WARNING: Do not operate the Yard Vacuum without a muffler or tamper with the exhaust system. Damaged mufflers or spark arresters could create a fire hazard.

CLEAN ENGINE

- Clean engine by removing dirt and debris with a cloth or brush.
- Frequently remove grass clippings, dirt, and debris from cooling fins, air intake screen, levers, and linkage. This will help ensure adequate cooling and engine speed.

SERVICE AND ADJUSTMENTS



WARNING: Do not at any time make any adjustment to the unit without first stopping engine and disconnecting spark plug wire.

Nozzle Height Adjustment

The nozzle can be adjusted to any six positions, ranging from 5/8" to 4 1/8" ground clearance. The nozzle height has to be adjusted according to the conditions. Move the height adjustment levers forward or backward to adjust the nozzle upwards or downwards. See Figure 14.

NOTE: In general, raise the nozzle height to vacuum a thick layer of leaves or to operate with the blower chute and lower the nozzle height for smoother surfaces.




Figure 14

CARBURETOR ADJUSTMENT



WARNING: If any adjustments (e.g. carburetor) are made to the engine while the engine is running, keep clear of all moving parts. Be careful of heated surfaces and muffler.

The carburetor has been pre-set at the factory and should not require adjustment. If your engine does not operate properly due to suspected carburetor problems, take your Yard Vacuum to a Sears Service Center for repair and adjustment.

ENGINE SPEED

The engine speed on your Yard Vacuum has been set at the factory. Do not attempt to increase the engine RPM. If you think that the engine is running too fast or too slow, take your Yard Vacuum to the nearest Sears Service Center for repair and adjustment.



WARNING: Do not attempt to alter the engine speed by tampering with the engine's governor linkage. Doing so could result in serious personal injury and damage to the engine. The engine RPM has been set at the factory.

REMOVING THE FLAIL SCREEN

If the discharge area becomes clogged, remove the flail screen and clean area as follows.

- Stop the engine. Make certain the chipper shredder vacuum has come to a complete stop.
- Disconnect and ground the spark plug wire before unclogging the discharge chute.
- Remove the vacuum bag or blower chute from the unit as instructed in the OPERATION section to obtain access to flail screen. See Figure 15.




Figure 15

 Remove hex screw on right side of unit that attaches to the flail screen. See Figure 16.




Figure 16

- Remove hex screw and flat washer on top of rear housing near mounting bracket and the lock nut that secures flail screen. See Figure 15.
- Remove and clean the screen by scraping or washing with water. Reinstall the screen.

14

SHARPENING OR REPLACING CHIPPER BLADE

Because the engine on this unit has a tapered crankshaft, a special impeller removal tool (part number 753-0900) is required to remove the impeller assembly. For further assistance, contact your Sears Service Center.

NOTE: When tipping the unit, empty the fuel tank and keep engine spark plug side up.

- Disconnect and ground the spark plug wire.
- Remove the front hubcaps, lock nuts, front wheels, and wave washers that attach to the pivot arm assemblies. See Figure 17.
- Remove the shoulder screws and bell washers that go through the pivot arms and height bracket adjusters to the front support brace.




Figure 17

 Remove the three screws on the upper housing that secure the nozzle cover and the nine screws that secure the lower housing to the upper housing. See Figure 18.




Figure 18

- Remove lock nut that secures flail screen to the lower housing. The flail screen does not have to be removed. Refer to Figure 15.
- Remove the hex bolt, lock washer, and flat washer that secure the impeller assembly to the crankshaft. See Figure 19.




Figure 19

- Apply lubricant to the threads of impeller removal tool and then thread the tool into the crankshaft.
 Stop when the impeller assembly can move on the crankshaft.
- Remove the impeller assembly from the crankshaft. Unthread the impeller removal tool from the impeller assembly.
- Remove the chipper blade using a 3/16" allen wrench on the outside of the blade and 1/2" wrench on the underside of impeller assembly.
- Replace or sharpen chipper blade.
- When sharpening blade, protect hands by using gloves and follow the original angle of grind.
- Reassemble by performing the previous steps in reverse order.
 - Tighten blade screws to 210 250 in-lbs.
 - Tighten impeller bolt to 375 425 in-lbs.

NOTE: Make certain chipper blade is reassembled with the sharp edge facing upward. See Figure 20.




Figure 20

STORAGE

Prepare your Craftsman Yard Vacuum for storage at the end of the season or if the unit will not be used for 30 days or longer. A yearly check-up by your local Sears Service Center is a good way to ensure that the unit runs properly next season.

Yard Vacuum

- · Clean the equipment thoroughly.
- Wipe equipment with an oiled rag to prevent rust.
 Use a light oil or silicone to wipe.
- Service the engine following instructions below.
- Store unit in a clean, dry area. Do not store next to corrosive materials such as fertilizer.

Engine

IMPORTANT: It is important to prevent gum deposits from forming in essential fuel system parts such as the carburetor, fuel filter, fuel hose, or tank during storage. Also, alcohol blended fuels (called gasohol or using ethanol or methanol) can attract moisture which leads to separation and formation of acids during storage. Acidic gas can damage the fuel system of an engine while in storage.

To avoid engine problems, the fuel system should be emptied before storage of 30 days or longer. Follow these instruction:

- Drain the fuel tank.
- Start the engine and let it run until the fuel lines and carburetor are empty.
- Drain carburetor.
- Never use engine or carburetor cleaner products in the fuel tank or permanent damage may occur.

NOTE: Fuel stabilizer is an acceptable alternative in minimizing the formation of fuel gum deposits during storage.

- Add stabilizer to gasoline in fuel tank or storage container.
- Always follow the mix ratio found on stabilizer container.
- Run engine at least 10 minutes after adding stabilizer to allow the stabilizer to reach the carburetor.
- Do not drain the gas tank and carburetor if using fuel stabilizer. Drain all the oil from the crankcase (this should be done after the engine has been operated and is still warm) and refill the crankcase with fresh oil.

If you have drained the fuel tank, protect the inside of the engine as follows:

- Remove spark plug, pour approximately 1/2 ounce (approximately one tablespoon) of engine oil into cylinder and crank slowly to distribute oil.
- Replace spark plug.

Other

- Do not store gasoline from one season to another.
- Replace the gasoline can if it starts to rust. Rust and/or dirt in the gasoline will cause problems.
- Store unit in a clean, dry area. Do not store next to corrosive materials, such as fertilizer.

NOTE: If storing in an unventilated or metal storage shed, be certain to rustproof the equipment by coating with a light oil or silicone.


TROUBLESHOOTING

Problem	Possible Cause(s)	Corrective Action
Engine fails to start	Fuel tank empty or stale fuel.	Fill tank with clean, fresh gasoline. Fuel will not last over thirty days unless a fuel stabilizer is added.
	2. Spark plug wire disconnected.	2. Connect wire to spark plug.
	Cannot pull recoil cord.	Obstruction lodged in impeller. Disconnect spark plug wire and remove lodged object.
	4. Choke not in ON position.	4. Move CHOKE to ON position.
	5. Faulty spark plug.	5. Clean, adjust gap or replace.
	6. Safety switch not depressed.	6. Safety switch must be depressed by the front tab on the bag handle when securing the bag.
	7. Safety switch wire is not	7. Connect safety switch wire to engine connector
	connected to engine or not	and ground to mounting bracket.
	properly grounded.	
Loss of power;	Spark plug wire loose.	Connect and tighten spark plug wire.
operation erratic	2. Unit running on CHOKE.	2. Move choke lever to OFF position.
•	3. Blocked fuel line or stale fuel.	3. Clean fuel line; fill tank with clean fresh
		gasoline. Fuel will not last over thirty days
		unless a fuel stabilizer is used.
	4. Water or dirt in fuel system.	4. Disconnect fuel line at carburetor to drain fuel
		tank. Refill with fresh fuel.
	Carburetor out of adjustment.	5. Contact your Sears Service Center.
	6. Low engine RPM.	6. Always run engine at full throttle.
Too much vibration	Loose parts or damaged impeller.	Stop engine immediately and disconnect spark plug wire. Have unit serviced by a Sears Service Center.
Engine overheats	Carburetor not adjusted	Contact your Sears Service Center.
_	2. Engine oil level low	2. Fill crankcase with proper selection of oil.
Unit does not discharge	Discharge chute clogged.	Stop engine immediately and disconnect spark plug wire. Clean flail screen and inside of discharge opening. See Maintenance section of this manual.
	Foreign object lodged in impeller.	Stop engine immediately and disconnect spark plug wire. Remove lodged object.
	3. Low engine RPM.	3. Always run engine at full throttle.
	4. Vacuum bag is full.	4. Empty bag.
Rate of discharge	Low engine RPM.	Always run engine at full throttle.
slows considerably or composition of discharged material changes	Chipper blade dull.	Replace chipper blade or see your Sears Service Center.

NOTE: For repairs beyond the minor adjustments listed above, please contact your local Sears Service Center.

PARTS LIST

Sears Craftsman 6.0 H.P. Yard Vacuum Model 247.770550




Sears Craftsman 6.0 H.P. Yard Vacuum Model 247.770550

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	720-0295	Foam Grip	30.	710-0502A	Hex Washer Screw 3/8-16 x 1.25
2.	749-1423	Upper Handle	31.	710-0751	Hex Cap Screw 1/4-20 x .620
3.	720-0279	Knob	32.	731-2484	Hose Base Adapter
4.	712-3004A	Flange Lock Nut 5/16-18	33.	716-0104	E Ring .500 Dia
5.	710-1205	Eye Bolt	34.	732-3035	Compression Spring
6.	781-1056	Upper Handle Bracket	35.	711-1571	Clevis Pin
7.	710-0528	Hex Cap Screw 5/16-18 x 1.25	36.	736-3020	Flat Washer271 ID x .630 OD
8.	720-0314	Handle Knob 5/16-18	37.	710-0969	Screw #12-16 x 1.0
9.	710-1174	Carriage Bolt	38.	710-0425	Machine Screw #10 - 24 x .625
11.	710-0604A	Hex Washer Screw 5/16-18 x.625	39.	781-1042	Upper Housing
12.	681-0174	Lower Handle Bracket	40.	726-0454	U-Clip Lock Nut 5/16-18
13.	749-0907B	Lower Handle	41.	710-3008	Hex Cap Screw 5/16-18 x.75
14.	711-1293	Studs	42.	681-0122	Chipper Chute Assembly
15.	710-0703	Carriage Screw 1/4-20 x.75	43.	738-1167	Stud 5/16-18 x .56
16.	712-0397	Wing Nut 1/4-20	44.	736-0371	Flat Washer .343 ID x .880 OD
17.	751B282454	Shroud	45.	781-1058	Hose Bracket Hanger
18.	725-1700	Switch Cover	46.	712-3027	Hex Flange Nut 1/4-20
19.	725-3166	Safety Switch	47.	748-0457	Spacer
20.	731-1613	Safety Switch Cover	48.	731-2478	Hose Nozzle
21.	710-0224	Hex Washer Screw #10-16 x.50	49.	710-3288	Hex Cap Screw 1/4-20 x 2.625
22.	629-0920	Wire Harness	50.	723-0295	Adjustment Clamp
23.	714-0104	Cotter Pin	51.	749-1270	Nozzle Handle
24.	736-0264	Flat Washer.330 ID x.630 OD	52.	764-0648	Vacuum Hose
25.	732-0962	Compression Spring	53.	07071	Handle Grip
26.	781-0778A	Mounting Bracket	54.	731-2292	Hose Adapter
27.	747-1153	Lock Rod	55.	736-0607	External L-Washer 5/16
28.	710-3195	Hex Cap Screw 5/16-18 x 4.5	56.	712-0161	Hex Lock Nut #10 - 24
29.	710-3025	Hex Cap Screw 5/16-18 x.625			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted polo green, the part number to order would be 700-xxxx-0689.

Polo Green: 0689 Oyster Grey: 0662 Powder Black: 0637

Sears Craftsman 6.0 H.P. Yard Vacuum Model 247.770550




Sears Craftsman 6.0 H.P. Yard Vacuum Model 247.770550

Ref. No.	Part No.	Part Description	Ref. No.	Part No.	Part Description
1.	664-0094	Bag Assembly	32.	732-1150	Torsion Spring RH
2.	681-0154	Screen Assembly	33.	731-2294	Nozzle Door
3.	710-1054	Hex Screw 5/16-24 x 1.0	34.	711-1582	Rod .25 x 1.25 Lg
4.	781-0490	Chipper Blade	35.	781-0725A	Front Wheel Support Brace
5.	681-0152	Impeller Assembly	36.	781-0777	Rear Wheel Support Brace
6.	781-0735	Pin Clip	37.	681-0155	Handle Bracket Ass"y LH
7.	719-0329	Flail Blade		681-0156	Handle Brkt Ass"y RH (Not Shown)
8.	715-0166	Spiral Pin	38.	714-0104	Cotter Pin
9.	711-1401	Clevis Pin	39.	710-3025	Hex Cap Screw 5/16-18 x.625
10.	736-0247	Flat Washer.375 ID x 1.25 OD	40.	736-0105	Bell Washer.401 ID x.870 OD
11.	736-0217	Lock Washer 3/8	41.	734-1992	Wheel 9 x 2
12.	710-0818	Hex Cap Screw 3/8-24 x 2.0	42.	736-0232	Wave Washer .531 ID x .781 OD
13.	710-3038	Hex Cap Screw 5/16-18 x .875	43.	738-1015	Shoulder Screw 3/8-16
14.	781-0721A	Lower Housing	44.	731-0981A	Hubcap
15.	712-3004A	Flange Lock Nut 5/16-18	45.	781-0785	Height Adjustment Bracket
16.	712-3027	Hex Flange Nut 1/4-20	46.	738-1185	Stud 5/16-18 .56 x .75
17.	736-0142	Flat Washer .281 ID x .50 OD	47.	741-0751	Height Adjustment Bearing
18.	714-0225	Cotter Pin	48.	682-0113	Pivot Arm Assembly
19.	711-1560	Pivot Rod	49.	720-0426	Height Adjustment Knob
20.	731-2294	Nozzle	50.	732-1026	Spring Lever
21.	781-1064	Base Adapter Door	51.	736-0741	Bell Washer .760 ID x .25 OD
22.	732-1156	Torsion Spring	52.	738-1173	Shoulder Screw .750 ID x .625 OD
23.	726-0106	Cap Speed Nut 1/4	53.	734-1978	Wheel 8 x 2
24.	711-1551	Pivot Rod	54.	712-0431	Flange Lock Nut 3/8-16
25.	712-0161	Hex Lock Nut #10-24	55.	726-0453	Lock Nut 3/8-16
26.	736-0400	Flat Washer .194 ID x .62 OD	56.	712-0158	Hex Lock Nut 5/16-18
27.	731-2485	Nozzle Door Lever	57.	736-0314	Thrust Washer .375 ID x .70 OD
28.	710-1156	Hex Screw #10-24 x 1.25	58.	OEM-290-012	Blower Chute (If Equipped)
29.	750-1294	Shoulder Spacer	59.	764-0631	Bag
30.	732-3118	Extension Spring	60.	631-0083	Chute Assembly
31.	732-1151	Torsion Spring LH			

NOTE: For **painted parts**, please refer to the list of color codes below. Please add the applicable color code, wherever needed, to the part number to order a replacement part. For instance, if a part, numbered 700-xxxx, is painted polo green, the part number to order would be 700-xxxx-0689.


Polo Green: 0689 Oyster Grey: 0662 Powder Black: 0637





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.


O990–2 Assemblies include all parts shown in frames.


6C–6/2002


















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

O990–5

Assemblies include all parts shown in frames.

6C–6/2002





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.


O990–6


Assemblies include all parts shown in frames.

6C–6/2002









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	493260	Cylinder Assembly			2678, 2679, 3120,			691375 Crankshaft
2		Kit-Bushing/Seal			3123, 3167, 3176.			(Used Before Code
		(Magneto Side)			493282 Crankshaft			Date 97011300).
3	±299819				(Used Before Code			Used on Type No(s).
		(Magneto Side)			Date 97011300).			1149, 1548.
4	493279	Sump-Engine			Used on Type No(s).			
		Note			0823, 1520, 1530,			692980 Crankshaft
		498983 Sump-Engine			1531, 1532, 1533,			(Used After Code Date
		Used on Type No(s).			1567, 2630, 2631.			97011200).
		1167, 1715, 1955,						Used on Type No(s).
		2320, 2324, 2331,			691452 Crankshaft			0658, 0660, 1570,
		2367, 2673, 2681,			(Used After Code Date			1758, 1760, 1763,
		3182.			97011200).			2634, 2670.
		696294 Sump-Engine			Used on Type No(s). 0664, 0665, 0666,			692005 Crankshaft
		Used on Type No(s).			0670, 0671, 0672,			(Used Before Code
		1717, 1718, 1719,			0840, 0866, 0868,			Date 97011300).
1 44	402265	1754, 2326, 3181.			0873, 0877, 1150,			Used on Type No(s).
4A	493303	Sump-Engine (Auxilliary PTO)			1166, 1170, 1171,			0658, 0660, 1758,
5	691160	Head-Cylinder			1332, 1366, 1368,			2634.
		Gasket-Cylinder Head			1370, 1371, 1372,			
8		Breather Assembly			1544, 1559, 1569,			692822 Crankshaft
_		Gasket-Breather			1770, 1771, 1784,			Used on Type No(s).
10		Screw			1919, 1920, 1926,			1766.
		(Breather Assembly)			1932, 1935, 1936,			691482 Crankshaft
11	691781	Tube-Breather			1941, 1942, 1943,			Used on Type No(s). 2329, 3183.
12	*692232	Gasket-Crankcase			1947, 1966, 1973, 1976, 1977, 1983,			694079 Crankshaft
13	690912				1976, 1977, 1983, 1985, 1985, 1988, 1991,			Used on Type No(s).
		(Cylinder Head)			1992, 2350, 2644,			1717, 1767, 1768,
15	691680	Plug-Oil Drain			2669, 2676, 3130,			1775.
	224222	(Square Socket)			3132, 3166, 3169,			692717 Crankshaft
15A	691093	Plug-Oil Drain			3181, 3313, 3314,			Used on Type No(s).
16	601451	(Hex Socket) Crankshaft			3315.			1955, 1986, 3178.
10	091431	(Used After Code Date			694059 Crankshaft			694478 Crankshaft
		97011200).			(Used Before Code			Used on Type No(s).
		Note			Date 97011300).			1777.
		493362 Crankshaft			Used on Type No(s).			694849 Crankshaft
		(Used Before Code			0866, 0868, 0873,			Used on Type No(s).
		Date 97011300).			0877, 1166, 1170, 1332, 1366, 1368,			1714, 2349, 2383,
					1370, 1371, 1544,			2391, 2635, 2683.
		691450 Crankshaft			1559, 1569, 1977.			694850 Crankshaft
		(Used After Code Date						Used on Type No(s).
		97011200).			691455 Crankshaft			2331, 2681.
		Used on Type No(s).			(Used After Code Date			696009 Crankshaft
		0823, 1520, 1530,			97011200).			Used on Type No(s).
		1531, 1532, 1533,			Used on Type No(s).			1720, 1776, 1778.
		1567, 1718, 1769,			1149, 1548, 1925,			696290 Crankshaft Used on Type No(s).
		1923, 1939, 1940,			2312, 2313, 2314,			2320.
		1950, 1951, 1952,			2315, 2316, 2324,			۵۵۵۷۰
		1979, 1980, 1987, 2375. 2376, 2379,			2328, 2349, 2352,			
		2380, 2609, 2610,			2360, 2370, 2373, 2381, 2383, 2384,			
		2611, 2612, 2630,			2394, 2395, 2396,			
		2631, 2667, 2677,			3172, 3173.			
		,,,			- · · - , • · · · • ·			
		ing Cooket Cot. Dof. No. 2				L		askat Cat. Bof. No. 077

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

	1000							
REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	*399781 *691952	(PTO Side)	25	499429	Piston Assembly (Standard) (Used After Code Date 97011200).	26	499425	Ring Set (Standard) (Used After Code Date 97011200).
22	691092	(Auxilliary PTO) Screw (Crankcase Cover/ Sump)						Note
23	692315	Flywheel (Rewind Start)			(Used Before Code Date 97011300).			Date 97011300).
23A		(Hewind Start) Flywheel (Electric Start)			499430 Piston Assembly (.010" Oversize) (Used After Code Date 97011200). 493385 Piston Assembly (.010" Oversize) (Used Before Code Date 97011300). 499431 Piston Assembly (.020" Oversize) (Used After Code Date 97011200). 493386 Piston Assembly (.020" Oversize) (Used Before Code Date 97011300). 499432 Piston Assembly (.030" Oversize) (Used After Code Date 97011200). 493387 Piston Assembly (.030" Oversize) (Used Before Code Date 97011300).	27	691866	499426 Ring Set (.010" Oversize) (Used After Code Date 97011200). 493388 Ring Set (.010" Oversize) (Used Before Code Date 97011300). 499427 Ring Set (.020" Oversize) (Used After Code Date 97011200). 493389 Ring Set (.020" Oversize) (Used Before Code Date 97011300). 499428 Ring Set (.030" Oversize) (Used After Code Date 97011200). 493390 Ring Set (.030" Oversize) (Used Before Code Date 97011300). Lock—Piston Pin (Used After Code Date 97011200). Note 691588 Lock— Piston Pin (Used Before Code Date 97011300).

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

REF.	PART		REF.	PART		REF.	PART	
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
28	499423	Pin-Piston	43	691997	Slinger-Governor/Oil	50		Manifold-Intake
		(Standard)			Note	51		Gasket-Intake
		(Used After Code Date			691486 Slinger–	54	691650	
		97011200).			Governor/Oil			(Intake Manifold)
		Note			Used on Type No(s).	55	691421	Housing-Rewind
		298909 Pin-Piston			1167, 1715, 2367, 2673, 3183.			Starter
		(Standard) (Used Before Code	45	600E40	Tappet–Valve	58	280399	Rope-Starter
		Date 97011300).	46		Camshaft			(Cut To Required
		298908 Pin–Piston	40	031443	(Used After Code Date		004404	Length)
		(.005" Oversize)			96060200).	60		Grip-Starter Rope
		(Used Before Code			Note	65	690837	
		Date 97011300).			492830 Camshaft	70	601100	(Rewind Starter)
29	499424	Rod-Connecting			(Used Before Code	78	691108	
_		(Standard)			Date 96060300).	81	601740	(Flywheel Guard) Lock-Muffler Screw
		Used After Code Date	46A	691460	Camshaft	83		Shaft–Auxiliary Drive
		97011200).			(Clockwise)		031110	Used on Type No(s).
		Note			(Used After Code Date			0823, 1923, 1947,
		490566 Rod-			96060200).			1949, 1989.
		Connecting			Used on Type No(s).			Note
		(Standard)			0823, 1923.			690527 Shaft-Auxiliary
		(Used Before Code			Note			Drive
		Date 97011300).			493740 Camshaft			Used on Type No(s).
		490743 Rod-			(Clockwise)			0662, 1315, 1538,
		Connecting			(Used Before Code			1762, 2312, 2313,
		(.020" Undersize)			Date 96060300).			2314, 2315, 2316,
		(Used Before Code			Used on Type No(s).			2351, 2352, 2360,
32	691664	Date 97011300).			0823. 691459 Camshaft			2378, 2385, 2394,
32	091004	(Connecting Rod)			(Counterclockwise)			3115, 3173.
32A	695759				(Used After Code Date			690521 Shaft-Auxiliary
UZA	030703	(Connecting Rod)			96060200).			Drive
		(Used After Code Date			Used on Type No(s).			Used on Type No(s).
		00042200).			0662, 1315, 1367,			1934, 1982, 2330.
33	262651	Valve–Exhaust			1538, 1762, 1934,	95	691636	Screw
34		Valve-Intake			1947, 1949, 1982,			(Throttle Valve)
35	691270	Spring-Valve			1989, 2312, 2313,	97	493267	Shaft-Throttle
		(Intake)			2314, 2315, 2316,			Note
36	691270	Spring-Valve			2330, 2351, 2352,			696565 Shaft–Throttle
		(Exhaust)			2360, 2378, 2385,			(Primer System)
37		Guard-Flywheel			2394, 3115, 3173.			(Used After Code Date
40	692194	Retainer-Valve			493738 Camshaft		400000	01040800).
					(Counterclockwise)	98A		Kit-Idle Speed
					(Used Before Code	101		Pin-Shaft
					Date 96060300).	104		Pin-Float Hinge
					Used on Type No(s).	108		Valve-Choke
					1538	109A	496593	Shaft-Choke
		ine Gasket Set_Ref. No 3				<u> </u>		sket Set_Ref No. 977

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

BEE			RFF	PART		RFF	PART	I
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
117A	494870	DESCRIPTION Jet-Main (Standard) ————————————————————————————————————	125A	498170	Carburetor (Primer System) (Used After Code Date 95102900). Note 498254 Carburetor (Primer System) Used on Type No(s). 1538. Carburetor (Choke System) Used on Type No(s). 1714, 1715, 1777, 1926, 1932, 1942, 1955, 2329, 2331, 2349, 2367, 2383,	133 134 137 146 159	398187 •398188 •693981 690979 691753 ••272653 691050	PISCRIPTION Float-Carburetor Kit-Needle/Seat Gasket-Float Bowl Key-Timing Bracket-Air Cleaner Primer Gasket-Air Cleaner Line-Fuel (15" Long) (Cut to Required Length) Line-Fuel (Molded) Line-Fuel (Included Filter) (1 1/3" And 4 5/8"
118	497315	Jet-Main (High Altitude) 496495 Jet-Main (High Altitude) Used on Type No(s). 1538. 498978 Jet-Main (High Altitude) Used on Type No(s). 0664, 0665, 0666, 0667, 0671, 0672, 1149, 1167, 1170, 1368, 1369, 1370, 1373, 1548.	127 130		2391, 2635, 2673, 2681, 3178, 3183. Note 498965 Carburetor (Choke System) Used on Type No(s). 0664, 0665, 0666, 0667, 0671, 0672, 1149, 1167, 1170, 1368, 1369, 1370, 1373, 1548. Plug—Welch Valve—Throttle Note	187C 188 190 202	690877 690940	Long) (Cut to Required Length) Line-Fuel (Molded) Used on Type No(s). 1717, 1718, 1719, 1754, 2326, 3181. Screw (Control Bracket)
118A 121	498260	Jet–Main (High Altitude) Kit–Carburetor Overhaul			696564 Valve—Throttle (Primer System) (Used After Code Date 01040800).			alat Sat. Ref. No. 077

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

	REF. PART DESCRIPTION 2390, 2394, 2395, 2396, 2632, 2634, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2348, 2670, 2671, 2672, 2675,
(Light Blue) (Yellow) Used on Type No(s). — Note — Sovernor 2329, 2349. 691290 Spring — Governor 690242 Spring — Governor (Meadow Green, 436 Load) Governor Used on Type No(s).	2396, 2632, 2634, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2348, 2670,
1932. 690241 Spring— Governor Used on Type No(s). 3183. 209A 690567 Spring—Governor (Platinum) Used on Type No(s). 1167. Note— 690568 Spring— Governor (Navajo White) Used on Type No(s). 1149, 1548. 691835 Spring— Governor (Meadow Green, 365 Load) Used on Type No(s). 0664, 0665, 0666, 0667, 1170, 1368, 1369, 1370, 1373. 262663 Spring— Governor (Purple) Used on Type No(s). 0671, 0672. 1935, 2681. 691291 Spring— Governor (Red) 1715, 1777, 1942, 1955, 1986, 2320, 2324, 2331, 2349, 2391, 3178. 690319 Spring— Governor (White) Used on Type No(s). 0652, 0656, 0661, 0662, 0822, 0824, 0839, 0877, 1148, 0662, 0822, 0837, 0838, 0839, 0877, 1148, 1315, 1316, 1322, 3154, 1354, 1354, 1354, 1354, 1544, 1547, 1569, 1570, 0667, 1170, 1368, 1571, 1721, 1752, 1756, 1766, 1761, 1771, 1784, 1922, (Purple) 1928, 1934, 1937, 1938, 1947, 1949, 0671, 0672.	2676, 2680, 2682, 2684, 2685, 3115, 3116, 3122, 3124, 3127, 3128, 3129, 3132, 3174, 3180, 3306, 3307, 3308, 3312, 3509, 6699. 691292 Spring—Governor (Black) Used on Type No(s). 0658, 0840, 0866, 0868, 0873, 1150, 1166, 1171, 1365, 1366, 1367, 1371, 1372, 1520, 1559, 1717, 1718, 1719, 1758, 1760, 1763, 1764, 1765, 1766, 1767, 1768, 1775, 1778, 1925, 1926, 1936, 1940, 1943, 1966, 1974, 1976, 1985, 1991, 1992, 2352, 3125, 3130, 3165, 3179, 3181, 3314, 3315. 691852 Spring—Governor (Purple) Used on Type No(s). 0670, 1720, 2379, 2380, 3169. 693187 Spring—Governor (Silver) Used on Type No(s). 2383, 2683.

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

222 6 222A 6	692031 692021 693006 692150	Spring-Choke Return Bracket-Control (Remote/Manual Friction)(Primer) Bracket-Control (Remote, Choke A Matic, Non Compliance) Note 690839 Bracket- Control (Manual Friction) (Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket-Control (Fixed Speed Auto Primer Control) Bracket-Control (Variable Speed) (5 Position Manual	276 • 287 300 300A 300B 304	690940 692038 494343 497681	(Dipstick Tube) Muffler (Super Lo Tone) Muffler (Square Lo Tone)	305 306 307 309 310 332	690345 695550 692327 690662	(Blower Housing) Shield-Cylinder Screw (Cylinder Shield) Motor-Starter (Used After Code Date 00040600). ———————————————————————————————————
222B 6	693006 692150	Friction)(Primer) Bracket–Control (Remote, Choke A Matic, Non Compliance) ————————————————————————————————————	300A 300B	692038 494343 497681	Screw (Dipstick Tube) Muffler (Super Lo Tone) Muffler (Square Lo Tone) Muffler (Catalyst) Housing-Blower Note 493294 Housing- Blower Used on Type No(s). 0666, 0667, 0868,	307 309 310 332	690345 695550 692327 690662	Shield-Cylinder Screw (Cylinder Shield) Motor-Starter (Used After Code Date 00040600). ———————————————————————————————————
222B 6	693006 692150	Bracket–Control (Remote, Choke A Matic, Non Compliance) ————————————————————————————————————	300A 300B	494343 497681	Muffler (Super Lo Tone) Muffler (Square Lo Tone) Muffler (Catalyst) Housing—Blower — Note 493294 Housing— Blower Used on Type No(s). 0666, 0667, 0868,	309 310 332	695550 692327 690662	(Cylinder Shield) Motor–Starter (Used After Code Date 00040600). Note 691376 Motor–Starter (Used Before Code Date 00040700). Bolt (Starter Motor) Nut
222B 6	693006 692150	(Remote, Choke A Matic, Non Compliance) ————————————————————————————————————	300A 300B	494343 497681	(Super Lo Tone) Muffler (Square Lo Tone) Muffler (Catalyst) Housing-Blower Note 493294 Housing- Blower Used on Type No(s). 0666, 0667, 0868,	310 332	692327 690662	Motor–Starter (Used After Code Date 00040600). ——————————————————————————————————
	692150	Choke A Matic, Non Compliance) Note 690839 Bracket— Control (Manual Friction) (Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket—Control (Fixed Speed Auto Primer Control) Bracket—Control (Variable Speed)	300B	497681	Muffler (Square Lo Tone) Muffler (Catalyst) Housing-Blower	310 332	692327 690662	(Used After Code Date 00040600). ———————————————————————————————————
	692150	Non Compliance) Note 690839 Bracket— Control (Manual Friction) (Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket—Control (Fixed Speed Auto Primer Control) Bracket—Control (Variable Speed)	300B	497681	(Square Lo Tone) Muffler (Catalyst) Housing-Blower	332	690662	00040600). Note 691376 Motor—Starter (Used Before Code Date 00040700). Bolt (Starter Motor) Nut
	692150				Muffler (Catalyst) Housing–Blower — Note 493294 Housing– Blower Used on Type No(s). 0666, 0667, 0868,	332	690662	
	692150	690839 Bracket— Control (Manual Friction) (Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket—Control (Fixed Speed Auto Primer Control) Bracket—Control (Variable Speed)			(Catalyst) Housing–Blower ————————————————————————————————————	332	690662	691376 Motor-Starter (Used Before Code Date 00040700). Bolt (Starter Motor) Nut
	692150	Control (Manual Friction) (Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket–Control (Fixed Speed Auto Primer Control) Bracket–Control (Variable Speed)	304	493293	Housing-Blower	332	690662	(Used Before Code Date 00040700). Bolt (Starter Motor) Nut
	692150	(Manual Friction) (Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket–Control (Fixed Speed Auto Primer Control) Bracket–Control (Variable Speed)	304	130230	Note 493294 Housing— Blower Used on Type No(s). 0666, 0667, 0868,	332	690662	Date 00040700). Bolt (Starter Motor) Nut
	692150	(Choke A Matic) Used on Type No(s). 1149, 1167, 1548. Bracket–Control (Fixed Speed Auto Primer Control) Bracket–Control (Variable Speed)			493294 Housing– Blower Used on Type No(s). 0666, 0667, 0868,	332	690662	Bolt (Starter Motor) Nut
	692150	Used on Type No(s). 1149, 1167, 1548. Bracket–Control (Fixed Speed Auto Primer Control) Bracket–Control (Variable Speed)			Blower Used on Type No(s). 0666, 0667, 0868,			Nut
	692150	Bracket–Control (Fixed Speed Auto Primer Control) Bracket–Control (Variable Speed)			0666, 0667, 0868,			
	692150	(Fixed Speed Auto Primer Control) Bracket–Control (Variable Speed)				000	000574	(Flywheel)
222C 6		Primer Control) Bracket–Control (Variable Speed)			1149 1150 1167	1 222		
222C 6		Bracket–Control (Variable Speed)				333		Armature–Magneto
2220		(Variable Speed)			1171, 1369, 1548,	334	691061	
	692467				1559, 1569, 1714, 1715, 1766, 1777	337	902502	(Magneto Armature)
	692467				1715, 1766, 1777, 1919, 1926, 1932,	346	690661	Plug-Spark
	692467	Choke)			1941, 1942, 1955,	340	030001	(Spark Arrestor)
222D 6		Bracket-Control			1988, 2320, 2324,	347	691396	Switch-Rocker
		(Fixed Speed)			2329, 2331, 2349,	356		Wire-Stop
222E 6	692982	Bracket-Control			2350, 2367, 2383,	356A		Wire-Stop
		(Manual Friction,			2391, 2635, 2669,	356B		Wire-Stop
		5 Position Manual			2673, 2681, 3110,	356D		Wire-Stop
		Choke)			3120, 3123, 3133,	356F		Wire-Stop
227	690783	Lever–Governor			3167, 3176, 3178,	358		Gasket Set–Engine
236	601926	Control Link–Lockout			3179, 3183. 695892 Housing–	359	691077	Washer (Ground Terminal)
		Filter–Fuel			Blower	363	19069	Flywheel Puller
		Bracket–Casing Clamp			Used on Type No(s).	365	692524	
		(Control Wire Casing)			1721, 1784, 1989,			(Carburetor)
		Clamp-Casing			2320, 2360, 2370,	373	691612	Nut
267 6	691044				2384, 2385, 2386,			(Ground Terminal)
		(Casing Clamp)			2389, 2390, 2394,	374	691074	Washer
268 6	691072	Casing–Control Wire			2395, 2641, 2643,	000	00000	(Camshaft)
		(48" Long) (Cut to Required Length)			2646, 2684, 2685, 3129, 3180, 3182,	383 404		Wrench-Spark Plug Washer
269 6	691589	Wire-Control			3308, 3509.	101	030212	(Governor Crank)
	00.000	(54" Long) (Cut to			696298 Housing-	425A	690670	
		Required Length)			Blower			(Air Cleaner Cover)
270	691027	Nut			Used on Type No(s).	443A	692523	Screw
		(Control Wire Casing)			1717, 1718, 1719,			(Air Cleaner Primer
271 6	691028	Lever-Control			1754, 2326, 3181.			Base)

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

DEE	DADT		DEE	DADT		DEE	DADT	
REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
445A	491588	Filter–Air Cleaner	601	95162	Clamp-Hose	689		Spring–Friction
		Cartridge	604	691757	Cover-Control	692	690572	Spring-Detent
455		Cup-Flywheel	604A	691344	Cover-Control	697	691127	Screw
456	692299	Plate-Pawl Friction	608	497680	Starter-Rewind			(Drive Cap)
459		Plate-Ratchet	613	691340	Screw	715	691693	Screw
474		Alternator			(Muffler)			(Shaft Stop)
497	690664		613A	691653	Screw	718	690959	Pin-Locating
		(Stop Switch Bracket)			(Muffler)	721		Stop-Shaft
500	691086	Washer	613B	691114		741		Gear-Timing
		(Key Switch)			(Muffler)	742	93941	Retainer–E Ring
505	691251		615	690340	Retainer-Governor	743	691772	Gear-Drive
		(Governor Control			Shaft			(Counterclockwise)
F07	604070	Lever)	616		Crank-Governor			Note
507		Insulator	617★	◆270344	Seal–O Ring			690516 Gear–Drive
510 512	-	Drive-Starter			(Intake Manifold)			(Clockwise)
513 520		Clutch-Drive	621		Switch-Stop			Used on Type No(s).
520 523		Terminal-Ground	627		Bracket-Stop Switch			0823.
523	450204	Dipstick Note —	633	●+691321	Seal-Choke/Throttle	745	691648	
		499621 Dipstick			Shaft			(Brake)
		Used on Type No(s).			(Throttle)	783	691918	Gear-Pinion
		1720.	633A ●	♦ 693867	Seal-Choke/Throttle			(19 Teeth)
524	+602206	Seal-Dipstick Tube			Shaft			(Starter Drive)
525		Tube-Dipstick			(Choke)	783A	691269	Gear-Pinion
529		Grommet	635	66538	Boot-Spark Plug			(12 Teeth)
544		Armature–Starter	651	93490		784		Cover-Starter Gear
545		Washer Set			(Starter Gear Cover)	785	692352	Gasket-Starter Cover
0.0	.020.0	(Starter Motor)	664	691087	Nut	789	695551	Harness–Wiring
562	92613				(Key Switch)			Used on Type No(s).
"	0_0.0	(Governor Control	668	*493823	Spacer			3179.
		Lever)			(Includes 2)	789A	695552	Harness–Wiring
564	690664	•	670		Spacer-Fuel Tank			(Used After Code Date
		(Control Cover)	676	396548	Deflector-Muffler			00040600).
		Note			(Louvered)			Note
		691132 Screw	676A	393756	Deflector-Muffler			691372 Harness–
		(Control Cover)			(Side Out)			Wiring
564A	691142		676B	397931				(Used Before Code
		(Control Cover)			(Direct Out)			Date 00040700).
584	692342	Cover-Breather	676C	493871	Deflector–Muffler	789B	696547	Harness–Wiring
		Passage		00000	(Side Out) (Extended)			Used on Type No(s).
585	★691879	Gasket-Breather	677	690661				0665, 0672, 1373,
		Passage		00004=	(Muffler Deflector)			1936, 1990, 1991,
592	690800		684	690345				2388, 2396, 2648,
	004000	(Rewind Starter)			(Breather Passage			3127, 3130, 3312,
597	691696				Cover)			3315.
		(Pawl Friction Plate)						
		ing Cooket Cat. Def. No. 20				<u> </u>	. =	aket Cet. Def. No. 077

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

 [◆] Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

REF.	PART		REF.	PART		REF.	PART	1
NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION	NO.	NO.	DESCRIPTION
801		Cap-Drive	870	690380	Seat-Valve	923	691994	
802	695267	Cap-End			(Exhaust)	923A	695891	
		(Used After Code Date	871	262001	Bushing-Valve Guide	925		Cover-Linkage
		00040600).			(Exhaust)	930	691919	Guard-Rewind
		Note 695975 Cap-End			Note	930A	601245	(Round) Guard–Rewind
		(Used Before Code			63709 Bushing–Valve	930A	091343	(Teardrop)
		Date 00040700).			Guide	935	499421	Switch-Interlock
803	695266	Housing-Starter	002 /	Ø601001	(Intake) Gasket–Exhaust	303	733721	(Used After Code Date
	000_00	(Used After Code Date	892		Switch–Key			92100600).
		00040600).	910	691094	-			Note
		Note	3.0	031034	(Alternator)			398758 Switch-
		695975 Housing-	921	497233	Cover–Blower Housing			Interlock
		Starter	V		(Static Guard) (5.5)			(Used Before Code
		(Used Before Code			Note			Date 92100700).
		Date 00040700).			692933 Cover-Blower	937		Spline-Starter
832		Guard-Muffler			Housing	940	690664	
832A		Guard-Muffler Guard-Muffler			Used on Type No(s).			(Casing Clamp Bracket)
832B 836	690664				1520, 1530, 1531,	957	207074	Cap-Fuel Tank
630	090004	(Muffler Guard)			1567, 2611, 2612,	931	391914	(Plastic)
836A	690661				2630, 2631, 2667,			(Black)
****		(Muffler Guard)			2678.			Note
836B	691147		921A	695886	Cover–Blower Housing			692662 Cap-Fuel
		(Muffler Guard)	0045	000001	(Black)			Tank
842	★691031	Seal-O Ring	921B	692931	Cover–Blower Housing			(Plastic)
		(Dipstick Tube)			(Static Guard) (XTE) Used on Type No(s).			(Red)
843	691884	Sleeve-Lever			2320, 2331, 2626,			Used on Type No(s).
	004005	(Speed Control)			2391, 2396.	0574	000040	2384, 3312.
843A	691895	Sleeve-Lever	921C	695889	Cover–Blower Housing	957A	692046	Cap-Fuel Tank
847	602017	(Choke) Dipstick/Tube	00		(Static Guard)	966A	/06116	(Plastic) Base–Air Cleaner
047	032017	Assembly			(Satin Black)	300A	430110	Primer
		Note			Used on Type No(s).	967A	493537	Filter–Pre Cleaner
		692047 Dipstick/Tube			2324, 2384, 2385,	968B		Cover-Air Cleaner
		Assembly			2386, 2387, 2388,	969	690700	Screw
		Used on Type No(s).			2389, 2390, 2394,			(Blower Housing
		1720.			2395.			Cover)
851		Terminal-Spark Plug	921E		Cover–Blower Housing	969A	691138	
853		Adapter–Wire	921F		Cover–Blower Housing			(Blower Housing
869	691155	Seat-Valve	922		Spring-Brake			Cover)
		(Intake)	922A	692135	Spring-Brake			

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

12H800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
970	691669	Screw (Air Cleaner Primer Bracket)	1019 1036		Kit-Label Emission Label (Used After Code Date	1059	692311	Kit-Screw/Washer Note 696293 Kit-Screw/
972B	495224	Tank–Fuel (Plastic) ——— Note ——— 499618 Tank–Fuel			99093000).			Washer Used on Type No(s). 1717, 1718, 1719, 1754, 2326.
975	493640	(Plastic) Used on Type No(s). 1720, 2384. 695960 Tank–Fuel (Plastic) Used on Type No(s). 1717, 1718, 1719, 1754, 2326, 3181. Bowl–Float			(Used After Code Date 98123100 and Before Code Date 99100100). 499341 Emission Label (Used After Code Date 97052500 and Before Code Date 99010100).	1095 1102		Gasket Set-Valve Pilot-Guide Used on Type No(s). 1167, 1715, 2367, 2673. Note 691255 Pilot-Guide Used on Type No(s).
976		Primer–Carburetor (Used After Code Date			499340 Emission Label (Used Before Code	1119	691648	1955, 2681, 3183. Screw (Alternator)
		99051200). ——— Note ——— 496115 Primer—			Date 97052600). 697378 Emission	1160	691627	,
		Carburetor (Used Before Code			Label (Used on Engines with Trim D1)	1210	498144	Pulley/Spring Assembly (Pulley)
977 986		Date 99051300). Gasket Set–Carburetor Filter–Debris Foam	1058	275177	Owner's Manual Note	1211	498144	Pulley/Spring Assembly
990 990A	691959	Key Set Key Set			274940 Owner's Manual	1236	695959	(Spring) Starter–Mechanical
994 1009		(Touch N Mow) Arrestor–Spark Screw			Used on Type No(s). 1717, 1718, 1719, 1754, 2326.			(Touch N Mow) (Do Not Service Individual Parts, Only As A Whole)
		(Starter Motor)						Only As A Whole)

[★] Included in Engine Gasket Set–Ref. No.358.
◆ Included in Carburetor Overhaul Kit–Ref. No. 121.

Included in Carburetor Gasket Set–Ref. No. 977.
 Ø Included in Valve Gasket Set–Ref. No 1095.

CONTENIDO						
Contenido	Página	Contenido	Página			
Garantía	38	Servicio y ajustes	50			
Seguridad	39	Almacenamiento	52			
Montaje	41	Localización de averías	53			
Operación	44	Lista de repuestos	18			
Mantenimiento	48					

GARANTIA

Garantía de un año sobre la aspiradora para jardines Craftsman

Por un período de un año a partir de la fecha de compra, Sears reparará gratis cualquier defecto en el material o fabricación de esta aspiradora para jardines Craftsman, siempre y cuando haya sido mantenida, lubricada y afinada de acuerdo a las instrucciones de manejo y mantenimiento dadas en el manual del operador.

Esta garantía excluye las cuchillas, cuchillas astilladoras, flagelos, filtros de aire, bujías, recolectores y neumáticos, consideradas piezas consumibles que se gastan durante el uso normal.

LA GARANTIA DE SERVICIO ESTA DISPONIBLE PONIENDOSE EN CONTACTO CON EL CENTRO DE SERVICIO SEARS MAS CERCANO EN EE.UU. ESTA GARANTIA TIENE VALIDEZ SOLAMENTE MIENTRAS EL PRODUCTO SE ENCUENTRA EN USO EN LOS ESTADOS UNIDOS.

Esta garantía le da derechos legales específicos, y usted puede tener otros derechos los cuales varían de un estado a otro.

Sears, Roebuck and Co., D/817WA, Hoffman Estates, II 60179

ASPIRADORA PARA JARDINES

ATENCION: Antes de usar este producto, lea este manual y respete todas las reglas de seguridad e instrucciones de manejo.

ESPECIFICACIONES DEL PRODUCTO								
Potencia:	6.0 caballos de fuerza	Número de modelo						
Tipo de aceite de motor	SAE 30	Número de serie						
Capacidad de aceite de motor	20 onzas	Fecha de compra						
Capacidad de combustible:	1 1/2 cuartos de galón	·						
Bujía	Champion RJ-19LM	Anote el número de serie y la fecha de compra y guárdelos en un lugar seguro para usar de						
Distancia entre electrodos		referencia en el futuro.						

SEGURIDAD



ADVERTENCIA: Este símbolo indica instrucciones de seguridad muy importantes las que, si no se siguen, podrían poner en peligro la seguridad personal y/o causar daños físicos. Antes de intentar manejar esta aspiradora para jardines, se debe leer y seguir todas las instrucciones que aparecen en este manual. Si no se cumplen estas instrucciones se corre el riesgo de sufrir lesiones. Cuando en el manual aparece este símbolo, respetar su advertencia.

ADVERTENCIA: El gas de escape emitido por el motor de esta máquina contiene componentes químicos que en el Estado de California son considerados como causantes de cáncer, defectos de nacimiento u otros daños a los órganos de la reproducción.

ADVERTENCIA: La aspiradora para jardines fue fabricada para ser manejada de acuerdo a las reglas de seguridad descritas en este manual. Como sucede con cualquier tipo de equipo motorizado, el descuido o error de parte del operador puede tener como resultado graves lesiones. Esta máquina es capaz de amputar dedos y manos y lanzar objetos con fuerza. Si no se siguen las instrucciones de seguridad siquientes se está expuesto a sufrir graves lesiones o la muerte.

OPERACION EN GENERAL

- Leer todo este manual del operador cuidadosamente antes de intentar armar la máquina. Leer, comprender y seguir todas las instrucciones que se encuentran en la máquina y en el manual (manuales) antes de manejarla. Aprender completamente el manejo de los controles y el uso correcto de la máquina antes de manejarla. Guardar este manual en un lugar seguro para usarlo como un libro de consulta en el futuro y cuando sea necesario pedir piezas de repuesto.
- La aspiradora para jardines es una herramienta muy potente, no es un juguete. Por lo tanto, actuar con sumo cuidado en todo momento. La máquina fue diseñada para astillar, triturar, aspirar y soplar (cuando está equipada con el accesorio) la vegetación encontrada en un jardín o patio normal. No se debe usar para ningún otro propósito.
- No dejar nunca que niños menores de 16 años de edad manejen esta máquina. Los niños mayores de 16 años siempre deben manejarla bajo la supervisión de un adulto. Solamente debe permitírseles manejar esta máquina a las personas responsables que conozcan bien estas reglas de seguridad de manejo.
- Mantener el lugar de trabajo despejado de personas, especialmente niños pequeños. Apagar el motor cuando se encuentren cerca de la máquina.
- Cuando se esté introduciendo material a este equipo, tener mucho cuidado de no incluir pedazos de metal, rocas, botellas, latas u otros objetos extraños. Se podría causar lesiones personales o dañar la máquina.
- Siempre usar anteojos o gafas de seguridad, durante el manejo y mientras se hacen ajustes o reparaciones, para protegerse los ojos contra objetos extraños que puedan ser lanzados por la máquina.
- Usar zapatos de trabajo gruesos y con suela áspera, y pantalones y camisa bien ceñidos. Se recomienda usar camisas y pantalones que cubran los brazos y las piernas, y zapatos con puntas de acero. No usar ropa suelta o joyas, y atarse el cabello más arriba de los hombros. Pueden quedar

- atrapados en las piezas en movimiento. Nunca manejar la máquina descalzo, con sandalias o zapatillas. Ponerse guantes para introducir el material en el tubo de triturado.
- No manejar la máquina si se ha ingerido alcohol o drogas.
- No tratar de alcanzar más lejos de lo normal.
 Mantener bien apoyado los pies y buen equilibrio en todo momento.
- No poner nunca las manos ni ninguna parte del cuerpo o indumentaria cerca de las piezas que están girando. Siempre mantenerse alejado de las bocas de descarga. Nunca meter las manos ni ninguna parte del cuero o indumentaria en la boquilla, tubo de triturar o boca de descarga, pues el rotor giratorio puede causar graves lesiones.
- Si por cualquier razón es necesario desatascar la toma de alimentación o la boca de descarga o inspeccionar o reparar alguna pieza de la máquina en una parte donde una pieza en movimiento podría quedar en contacto con el cuerpo o indumentaria, apagar el motor, esperar hasta que se enfríe, desconectar el cable de la bujía y apartarlo de la bujía antes de intentar desatascar, inspeccionar o reparar.
- Nunca manejar la máquina sin que tenga instalado el recolector de la aspiradora o, si está equipada con tubo soplador, bien conectado a la máquina. El extremo abierto grande del recolector (bolsa) debe estar cerrado para impedir que salgan objetos soplados por la parte trasera del recolector.
- Cuando se trabaje con la función de soplador (esta máquina puede tener incluido el accesorio de tubo de soplado opcional):
 - No situarse ni caminar delante de la boca de descarga del soplador ni apuntársela a las personas, animales, vehículos, etc. que se encuentren cerca. Los objetos que salen lanzados por la boca de descarga puede causar lesiones personales o daños a la propiedad.
 - No dirigir la descarga del soplador contra una pared u otra obstrucción vertical. El material descargado puede rebotar hacia el operador.
 - Ajustar la altura de la boquilla de aspiración a la posición más alta para reducir la posibilidad de que aspiren objetos más pesados (por ej.,

piedras, pedazos de vidrio o de metal) y sean lanzados por la boca de descarga. Al elevar la boquilla a la posición más alta también incrementa la admisión de aire para lograr mejor funcionamiento del soplador.

- No intentar nunca retirar o vaciar el recolector mientras el motor está funcionando. Apagar el motor y esperar hasta que el rotor esté detenido antes de retirar el recolector (bolsa). El rotor continúa girando por algunos segundos después de apagar el motor. Nunca acercar ninguna parte del cuerpo al área del rotor sin antes asegurarse de que ha parado de girar.
- Mantener todos los protectores y dispositivos de seguridad en su lugar y en buen estado de funcionamiento.
- No dejar que se acumule material tratado en el área de descarga, pues impedirá la descarga adecuada.
- Cuando se introduzca material en la astilladora, no situarse con la cara o el cuerpo directamente delante del tubo de la astilladora. Situarse a un lado. El material que se está introduciendo puede rebotar fuera del tubo.
- Si el mecanismo de corte choque con un objeto extraño o si la máquina empieza a hacer un ruido o vibración inusual, apagar inmediatamente el motor, desconectar el cable de la bujía y apartarlo de la bujía. Dejar que la máquina se pare y proceder de la manera siguiente:
 - · Buscar si hay daño
 - Reparar o cambiar las piezas dañadas.
 - Buscar piezas flojas y apretarlas para asegurar un buen funcionamiento.
- El silenciador y el motor se calientan y puede causar quemaduras. No tocarlos.
- No dejar que las hojas u otros desechos se acumulen en el silenciador del motor. Los desechos pueden encenderse y causar un incendio.
- No hacer funcionar el motor si el filtro de aire o la tapa encima de la toma de aire del carburador no está colocada. El retiro de dichas piezas puede crear un peligro de incendio.

NIÑOS

Pueden ocurrir accidentes de trágicas consecuencias si el operador no está alerta a la presencia de niños pequeños. Los niños son frecuentemente atraídos a los lugares donde se está astillando y aspirando hojas, ramas, etc. Nunca suponer que los niños van a permanecer en el lugar donde se les vio la última vez.

- No dejar que los niños se acerquen al lugar de trabajo y mantenerlos vigilados por un adulto aparte del operador.
- Estar alerta y apagar el motor si un niño se aproxima al lugar.
- Nunca permitir que niños menores de 16 años de edad manejen la aspiradora para jardines.

SERVICIO

- Tener sumo cuidado cuando se maneje gasolina y otros combustibles. Son muy inflamables y sus vapores son explosivos.
 - Guardar el combustible y el aceite en contenedores aprobados, lejos del calor y llamas expuestas, y lejos del alcance de los niños.
 - Revisar el nivel y cargar combustible antes de arrancar el motor. Nunca quitar la tapa del tanque de combustible ni añadir combustible mientras el motor está funcionando. Siempre dejar que el motor se enfríe por lo menos durante dos minutos antes de cargar combustible.
 - Antes de arrancar el motor, colocar la tapa del tanque de gasolina bien apretada y limpiar con un trapo la gasolina que pueda haberse derramado ya que podría causar un incendio o explosión.
 - Apagar los cigarrillos, cigarros, pipas y otras fuentes de ignición.
 - Nunca cargar combustible en el interior de edificios porque pueden acumularse vapores inflamables en el área.
 - Nunca guardar la máquina o el contenedor de combustible en interiores donde haya una llama expuesta o chispas, como por ejemplo, un calentador de agua caliente, secadora de ropa o un calefactor de gas.
- No hacer funcionar nunca la máquina en un lugar cerrado pues el gas de escape del motor contiene monóxido de carbono, el cual es un gas inodoro, insípido y mortalmente venenoso.
- Para reducir el peligro de incendio, mantener el motor y el silenciador libres de hojas, pasto y otra acumulación de desechos. Limpiar el combustible y aceite derramado. Dejar que la máquina se enfríe durante por lo menos 5 minutos antes de guardarla.
- Antes de limpiar reparar o inspeccionar, cerciorarse de que el rotor y todas las piezas móviles se hayan detenido. Desconectar el cable de la bujía y apartarlo de la bujía para impedir el arranque accidental del motor. No usar soluciones inflamables para limpiar el filtro de aire.
- Mantener todas las tuercas, pernos y tornillos apretados para asegurar que el equipo esté en buenas condiciones de funcionamiento.
- Nunca estorbar los dispositivos de seguridad. Probar su funcionamiento periódicamente.
- Después de chocar con un objeto extraño, apagar inmediatamente el motor, desconectar el cable de la bujía y hacer una inspección minuciosa de la máquina en busca de algún daño. Reparar el daño antes de arrancar el motor y manejar la máquina.
- No alterar ni estorbar el ajuste del gobernador del motor. El gobernador controla la velocidad máxima segura del motor. El hacer funcionar el motor a sobrevelocidad es peligroso y se dañará el motor y las otras piezas móviles de la máquina.
- Revisar el recolector (bolsa) de la aspiradora frecuentemente. Cambiarlo si está desgastado o dañado.
- Mantener el recolector sin desechos cuando no esté en uso.

MONTAJE




Figura 1

IMPORTANT: Esta máquina salió de fábrica sin gasolina y sin aceite en el motor. Después de armarla, ver la sección OPERACION en este manual para informarse sobre el llenado de aceite del motor y el tipo de combustible.

NOTE: Para determinar los lados derecho e izquierdo de la aspiradora para jardines, situarse detrás de la máquina, en posición de manejarla. Ver la figura 1.

La aspiradora para jardines fue armada en la fábrica, con la excepción del manillar, recolector y tubo de soplado. Estos componentes se envían sueltos en la caja de cartón. En la caja también se incluyen anteojos de seguridad y una botella de 20 onzas de aceite para motor. Ver la figura 1.

DESEMBALAJE

- Cortar las esquinas de la caja.
- Quite todas las piezas flojas.
- Quite el material de embalaje.
- Levante la unidad de la parte posterior para desechar el material de embalaje de la unidad inferior y de la unidad del rodillo de cartón.
- Controle el cartón a conciencia para saber si hay cualquier otra pieza floja.

PIEZAS SUELTAS

Ver la figura 1

- Montaje del manillar
- Recolector (bolsa)
- Montaje del tubo de soplado
- Anteojos de seguridad (no se muestran)
- Botella de 20 onzas de aceite para motor
- Manual del operador

DESCONEXION DE LA BUJIA

Antes de comenzar a armar la nueva aspiradora para jardines, desconectar el cable de la bujía y conectarlo a tierra en el pilar retenedor en el motor. Esto impedirá el arranque accidental del motor. Ver la figura 2.





Figura 2

INSTALACION DEL MANILLAR

- Plegar el manillar superior hasta que quede alineado con el manillar inferior. Ver la figura 1.
- Fijarlo bien apretando las tuercas de mariposa superiores, las cuales conectan juntos los dos manillares.

- Retirar las chavetas de las escuadras del manillar y los tornillos de carruaje (cabeza de hongo y cuello cuadrado) y tuercas de mariposa del manillar inferior. Ver la figura 3.
- Colocar el manillar inferior sobre los pasadores en las escuadras y fijarlos con las chavetas, tornillos de carruaje y tuercas de mariposa.



- En el lado derecho del manillar superior se encuentra una guía para la cuerda. Aflojar la tuerca de mariposa que sujeta la guía.
- Tirar la cuerda de arranque fuera del motor lentamente y deslizarla a través de la guía.
 Apretar la tuerca de mariposa. Tolva de Soplador

Instalación del montaje de la manguera

- Deslice el adaptador para manguera del montaje de la misma hacia el interior del adaptador base ubicado a la izquierda y al frente de la aspiradora para patios. Ver Figura 4.
- Tire del perno con resorte del lado exterior de la base y ponga el perno en línea con el primer agujero del adaptador para manguera.
- Suelte el perno para ajustar la manguera en su lugar.
- Conecte la manija de la manguera ubicada cerca del extremo con pico de la misma al soporte lateral de la manija superior. Consulte Figura 4.





Figura 4

 Una a presión la manija de la manguera con el soporte de la manija inferior para ajustarla en su lugar y coloque el caño de la manguera en el gancho del soporte lateral que se encuentra próximo al canal de la cortadora. Consulte Figura 7.

INSTALACION DEL RECOLECTOR

- Asir el mango del recolector con una mano y, con la otra mano, tirar de la varilla de fijación en la escuadra de montaje hacia el motor. Use el final de soporte de montaje como el apalancamiento deslizando la barra que se cierra. Ver la Figura 5.
- Deslizar el recolector por encima del borde de la boca de descarga y soltar la varilla de fijación para sujetar el recolector en su lugar.
- Colocar las correas inferiores del recolector sobre el manillar inferior, enganchándolas en los espárragos.
- Encajar el clip del recolector en la parte superior del manillar inferior.



NOTE: Cuando se coloque el recolector en la máquina, el botón interruptor de seguridad adosado a la escuadra de montaje debe quedar totalmente oprimido por la lengüeta delantera ubicada en el mango del recolector, de lo contrario el motor no arrancará.

INSTALACION DEL TUBO DE SOPLADO

NOTE: Antes de instalar el tubo de soplado se debe retirar el recolector.

- Asir el tubo de soplado con una mano y, con la otra mano, tirar de la varilla de fijación en la escuadra de montaje hacia el motor. Use el final de soporte de montaje como el apalancamiento deslizando la barra que se cierra. Ver la Figura 6.
- Deslizar el tubo de soplado por encima del borde de la boca de descarga y soltar la varilla de fijación para sujetar el tubo en su lugar.
- Cuando se va a usar el tubo de soplado, elevar la boquilla a la posición más alta. Ver el ajuste de la boquilla en la sección AJUSTES.

NOTE: El botón interruptor de seguridad adosado a la escuadra de montaje debe quedar totalmente oprimido por la lengüeta delantera ubicada en tubo de soplado, de lo contrario el motor no arrancará.




Figura 6


OPERACION

Conozca su aspiradora para jardines

Lea este manual del operador y las reglas de seguridad antes de manejar su aspiradora para jardines. Compare las ilustraciones presentadas más abajo con su equipo para que conozca bien la ubicación de los



distintos controles y ajustes. Guarde este manual para consultarlo en el futuro. El manejo de cualquier aspiradora para jardines sopladora puede causar el lanzamiento de objetos extraños contra los ojos y lesionarlos gravemente. **Use siempre los anteojos de seguridad**, suministrados con la aspiradora para jardines Craftsman, para manejar este equipo o mientras le hace trabajos de ajuste o reparación.



CONTROLES DE OPERACION

Tubo de astillado

Permite introducir ramillas y ramas pequeñas de hasta 1-1/2" de diámetro en el rotor para astillarlas.

Boquilla

Los desechos del jardín tal como hojas y agujas de pino pueden aspirarse a través de la boquilla para luego triturarlos.

Recolector

Junta todo el material triturado que fue introducido a través del tubo de astillado o que fue aspirado a través de la boquilla.

Tubo de soplado

Cuando está instalado en la máquina, este tubo se usa para soplar o esparcir los desechos del jardín tal como hojas, agujas de pino o ramillas pequeñas.

Mango del recolector

Se usa para agarrar el recolector y poderlo instalar, retirar y vaciar.

Palanca de ajuste de altura de la boquilla

Se usa para ajustar la altura entre la boquilla y el suelo, variando de 5/8" a 4 1/8".

Palanca de estrangulador/control del acelerador

Esta palanca única controla la velocidad del motor, la función de parada y el estrangulador del carburador. Pasando por cuatro posiciones separadas en la palanca, de izquierda a derecha, el funcionamiento es el siguiente:



NOTE: De conformidad con las normas de seguridad de ANSI

NOTE: Las máquinas aspiradoras para jardines Craftsman cumplen con las normas de seguridad del Instituto de Normalización Nacional de EE.UU. (ANSI).

Montaje de la manguera

Se usa como alternativa del uso del pico para aspirar los desechos que se acumulan en los patios como por ejemplo las hojas o las agujas de los pinos que se encuentran en lugares de difícil acceso.

Manija de la manguera

Se utiliza para guiar el montaje de la manguera mientras se aspira.

Manija del pico / manguera de la aspiradora

La manija del pico / manguera de la aspiradora se encuentra en la parte superior del pico y se utiliza para regular la aspiración entre el pico y el montaje de la manguera.

Cebador

El cebador se usa para ayudar durante el arranque del motor en frío.

Mango de arranque

Se usa para arrancar el motor.

LLENADO DE GASOLINA Y ACEITE

Aceite (una botella de 20 onzas enviada con la máquina)

Usar únicamente aceite detergente de buena calidad clasificado con la clasificación de servicio SF, SG o SH de la API. Escoger el grado de viscosidad SAE del aceite de acuerdo con la temperatura de trabajo anticipada. Guiarse por el gráfico siguiente.



NOTE: Aunque los aceites de múltiple viscosidad (5W30, 10W30, etc.) mejoran el arranque del motor en climas fríos, causarán un mayor consumo de aceite cuando se usan a temperaturas sobre 32°F. (0°C). Revisar el nivel de aceite del motor frecuentemente para evitar el posible daño del motor en caso de funcionar con muy poco aceite.

- Retirar la varilla de medición de aceite.
- Con la aspiradora para jardines en suelo plano, usar un embudo para llenar el motor con aceite hasta la marca FULL (LLENO) en la varilla. La capacidad es de aproximadamente 20 onzas. Tener cuidado de no llenar demasiado. El exceso de aceite puede hacer humear el motor y reducir su buen funcionamiento. La botella de aceite incluida con la aspiradora para jardines contiene 20 onzas de aceite.
- Revisar el nivel de aceite asegurándose de no frotar la varilla a lo largo de las paredes interiores del tubo de llenado de aceite. Esto produciría

- una indicación errónea del nivel en la varilla. Llenar hasta la marca FULL, si es necesario. Volver a colocar la varilla de medición y apretarla.
- Revisar el nivel de aceite tres veces antes de arrancar el motor para cerciorarse de que se obtiene una indicación correcta en la varilla. Si se hace funcionar el motor con muy poco aceite se puede dañar para siempre.

Gasolina

- Quitar la tapa del tanque de gasolina.
- Asegurarse de que el contenedor del cual se verterá gasolina esté limpio y sin óxido o partículas extrañas. Nunca usar gasolina vieja que haya estado mucho tiempo guardada en el contenedor. La gasolina que ha estado en el contenedor por más de cuatro semanas deberá considerarse vieja.
- Llenar el tanque únicamente con gasolina para automóviles regular sin plomo, superior sin plomo o reformulada. NO usar etilo o gasolina de alto octanaje. No usar gasolina que contenga METANOL. Volver a colocar la tapa.
- Para evitar problemas en el motor, vaciar el sistema de combustible antes de guardar la máquina por 30 días o más tiempo. Vaciar el tanque de gasolina, arrancar el motor y dejar que funcione hasta que la tubería de combustible y el carburador estén vacíos. En la próxima temporada, usar combustible fresco. Para más información, ver la sección ALMACENAMIENTO.
- Nunca usar productos limpiadores del motor o carburador en el tanque de combustible, se puede causar daño permanente.



ADVERTENCIA: Nunca llenar el tanque de gasolina en el interior de un edificio, con el motor funcionando o mientras el motor está caliente. No fumar mientras se llena el tanque de gasolina. Para evitar derrames y permitir la expansión del combustible, llenar solamente hasta 1/2 pulgada de la parte superior del tanque de gasolina.

 Revisar el nivel de combustible periódicamente para evitar que se acabe la gasolina mientras la aspiradora para jardines está funcionando. Si a la máquina se le agota el combustible mientras está astillando, será necesario desatascar la máquina antes de volver a arrancar el motor. Ver la sección SERVICIO Y AJUSTES.

PARA APAGAR EL MOTOR

- Mover la palanca de control del acelerador a la posición STOP (APAGAR).
- Desconectar el cable de la bujía y conectarlo a tierra en el pilar retenedor para impedir el

arranque accidental mientras la máquina está sola.



ADVERTENCIA: Al mover la palanca de mando de válvula reguladora, tenga cuidado de superficies calentadas y de bordes sostenidos del silenciador quarde.

PARA ARRANCAR EL MOTOR

- 1. Asocie el cargador del programa inicial del alambre y del caucho del enchufe de chispa al enchufe de chispa.
- El botón del interruptor de bag/chute se debe presionar completamente por la extremidad de la tabulación delantera en la manija del bolso o el canal inclinado del soplador para que el motor comience.
- 3. Cerciórese de que alambre del interruptor de bag/chute esté conectado con el motor y que puesto a tierra al corchete de montaje.
- 4. El depósito de gasolina se debe llenar 3/4 por completo antes a empezar.
- 5. Cuando la temperatura es sobre 32°F (0°C):
- Mover la palanca de estrangulador/control del acelerador a la posición RAPIDO.
- Presione el bulbo superelegante firmemente con su pulgar tres veces. Espere cerca de dos segundos entre cada empuje. No utilice la cartilla para recomenzar un motor caliente después de una parada normal corta. Véase El Cuadro 8.

Cuando la temperatura esta por debajo de 32°F (0°C):

- Mover la palanca de estrangulador/control del acelerador a la posición ESTRANGULADOR.
 (Un motor caliente no siempre requiere el uso del estrangulador.) Ver la figura 8.
- Si no se va a usar el estrangulador para arrancar el motor, mover la palanca de estrangulador/ control del acelerador a la posición RAPIDO.
- Oprimir el cebador lentamente trace veces. Dejar pasar unos dos segundos entre cada empuje.

NOTE: Vea el filtro de aire en la cara del motor para las instrucciones más lejos que comienzan.




Figura 8

- 6. Estando parado detrás de la unidad, agarre la manija del arrancador y saque la cuerda hasta que usted siente una fricción.
- 7. Tire de la cuerda con un movimiento rápido, continuo, completo del brazo. Guarde un apretón firme en la manija del arrancador. Deje la cuerda rebobinar lentamente.
- Repetición, en caso de necesidad, hasta que el motor comienza. Cuando el motor comienza, mueva la palanca de la válvula reguladora / de la estrangulación gradualmente a la posición de START/run.
- 9. Si el motor vacila, mueva la palanca de mando a la posición de la ESTRANGULACIÓn, entonces de nuevo a la posición de START/run.
- Mantenga SIEMPRE el control de válvula reguladora la posición de START/run al funcionar el vacío de la yarda.

Descarga de la bolsa

- Desenganche las tiras de la bolsa de la manija inferior y desabroche el broche de la bolsa de la parte superior de la manija inferior. Ver Figura 9.
- Tome la manija de la bolsa con una mano y tire de la varilla de seguridad del soporte de montaje hacia el motor con la otra mano para soltarla.
- Saque la bolsa del borde de la abertura de descarga. Consulte Figura 4.
- Gire los dos botones de la parte posterior de la bolsa para abrirla y vaciar el contenido. Ver Figura 9.




Figura 9

 Sostenga la manija y el broche de la bolsa mientras vacía el contenido.

- Comprima la abertura de la bolsa y doble la aleta interior sobre la abertura.
- Doble la aleta exterior sobre la aleta interior e inserte los botones de la bolsa a través de las salidas metálicas.
- Gire los botones para cerrar la bolsa.

Extracción del canal de soplado

- Tome el canal de soplado con una mano y tire de la varilla de seguridad del soporte de montaje hacia el motor con la otra mano para soltarlo. Consulte Figura 6.
- Saque el canal de soplado del borde de la abertura de descarga.

Uso del pico de la aspiradora

- Coloque la manija del pico / manguera de la aspiradora en la posición superior del pico para aspirar a través del mismo. Ver Figura 10.
- El perno con resorte debe estar en el primer agujero de la adaptación de la manguera para operar el pico de la misma.
- Coloque ambas manos en la parte superior de la manija superior para desplazar la unidad por encima de los desechos acumulados en el patio.

El desecho que se acumula en los patios como por ejemplo las hojas y las agujas de los pinos pueden aspirarse a través del pico para triturarlos. Después que ha triturado el material con las hojas de desgranar del montaje del motor, el mismo será descargado a la bolsa colectora o a través del canal de soplado. Sólo utilice la máquina para triturar o picar el material integrante de la vegetación que se encuentra en un patio normal (es decir, ramas, hojas, ramas pequeñas, etc.) Evite las plantas fibrosas como por ejemplo las de tomates hasta que estén totalmente secas. Se pueden introducir materiales como por ejemplo troncos o ramas pesadas de hasta 1 1/2" de diámetro en el canal de la cortadora.




Figura 10

IMPORTANTE: La pantalla de desgranado está ubicada dentro de la caja en la zona de descarga. Si se tapa la pantalla de desgranado, sáquela y límpiela como se indica en SECCIÓN 5: MANTENIMIENTO DE LA ASPIRADORA PARA PATIOS. Para obtener el mejor resultado es importante también mantener afilada la hoja de la cortadora.



ADVERTENCIA: Siempre detenga el motor y desconecte el cable de la bujía antes de realizar cualquier ajuste.

Uso del montaje de la manguera

- Coloque la manija del pico / manguera de la aspiradora en la posición de la base del pico para volver a dirigir la aspiración al montaje de la manguera. Ver Figura 11.
- Para operar el ensamblado de la manguera, el perno con resorte debe estar en el segundo agujero del adaptador de la misma.
- Desenganche la manguera del soporte de la manija superior y tome la manija de la manguera para dirigirla mientras aspira los desechos que se acumulan en los patios como por ejemplo hojas o agujas de pinos que se encuentran en lugares de difícil acceso.




Figura 11

Ajuste de la altura del pico

Puede ajustar el pico en seis posiciones que varían desde 5/8" a 4 1/8" de distancia del suelo. Debe ajustar la altura del pico según las condiciones. Mueva las palancas para ajustar la altura hacia adelante o hacia atrás para ajustar el pico hacia arriba o hacia abajo. Ver Figura 11.

MANTENIMIENTO

	ROGRAMA DE ANTENIMIENTO							
РКОВИСТО	Lubricación						\triangleleft	
PROD	Limpiar el equipo		\checkmark					
	Revisar nivel aceite							
_	Campiar aceite motor						৶	
MOTOR	Limpiar filtro de aire				\triangleleft			
2	Limpiar la bujía					\triangleleft	\triangleleft	
	Limpiar el silenciador					\checkmark		
	Limpiar el motor						∜	

RECOMENDACIONES GENERALES

- Siempre respetar las reglas de seguridad durante los trabajos de mantenimiento.
- La garantía de esta máquina no cubre los componentes que han estado sujetos a maltrato o descuido. Para recibir todo el valor de la garantía, el operador debe conservar el equipo tal como se indica en este manual.
- Será necesario hacer algunos ajustes periódicamente para mantener el equipo en buen estado.
- Seguir el programa de mantenimiento.
- Revisar periódicamente todos los pernos, tornillos, tuercas, etc. y asegurarse que estén bien apretados.



ADVERTENCIA: Siempre apagar el motor, desconectar el cable de la batería y conectarlo a tierra antes de ejecutar el mantenimiento o los ajustes.

LUBRICACION

- Ruedas Una vez en la temporada, colocar unas pocas gotas de aceite SAE 30 en cada tornillo de reborde. Ver la Figura 7.
- Palancas de ajuste de altura de la boquilla -Lubricar estas palancas con aceite ligero. Ver la Figura 7.
- Varilla de fijación Lubricar la varilla y los resortes de compresión que se encuentra fijados a la escuadra de montaje. Ver la Figura 5.

LIMPIEZA DEL EQUIPO

- Limpiar a fondo la aspiradora para jardines después de cada uso.
- Lavar el recolector periódicamente con agua. Dejar secar a la sombra.
- Si la rejilla se obstruye, retirarla y limpiarla como se indica en la sección SERVICIO Y AJUSTES.

NOTE: No se recomienda limpiar la máquina con un chorro fuerte de agua ya que se podría contaminar el sistema de combustible.

REVISION DEL ACEITE DEL MOTOR

- Retirar la varilla de medición de nivel de aceite.
- Revisar el nivel de aceite en la varilla. Debe estar hasta la marca FULL (LLENO).
- Volver a colocar la varilla y apretarla.

CAMBIO DE ACEITE DEL MOTOR

- Usar únicamente aceite detergente de buena calidad clasificado con la clasificación de servicio SF, SG o SH de la API. Escoger el grado de viscosidad SAE del aceite de acuerdo con la temperatura de trabajo anticipada. Guiarse por el gráfico de viscosidad.
- Apagar el motor y dejar pasar varios minutos antes de revisar el nivel de aceite. Con la máquina en suelo nivelado, el aceite debe estar en la marca FULL (LLENO) en la varilla de medición.
- Cambiar el aceite después de las primeras cinco horas de funcionamiento, y de allí en adelante hacerlo cada veinticinco horas.

PARA VACIAR EL ACEITE

Vaciar el aceite mientras el motor está caliente. Seguir las instrucciones siguientes.

- Vaciar el tanque de gasolina, arrancar el motor y dejarlo funcionando hasta que la tubería de combustible y el carburador estén vacíos.
- Retirar la varilla de medición de llenado de aceite.
- Inclinar la máquina sobre su costado para vaciar el aceite por el tubo de llenado.
- Una vez que se ha vaciado todo el aceite del motor, volver a llenar con aproximadamente 20 onzas de aceite fresco. Ver el párrafo sobre Llenado de gasolina y aceite en la sección OPERACION.
- Volver a colocar la varilla de medición.

SERVICIO DEL FILTRO DE AIRE

El filtro de aire impide la tierra, polvo, etc. dañinos entren al carburador y sean empujados al interior del motor, y es importante para la duración y funcionamiento del motor. El filtro de aire es un filtro de espuma de uretano. **Nunca hacer funcionar** el motor sin tener el filtro de aire totalmente armado.

Para limpiar el filtro de aire:

- Retirar el filtro de espuma de la caja de plástico ubicada encima del motor.
- Lavar en una solución de agua y detergente, y exprimirlo (sin estrujarlo) hasta quitarle todas las impurezas.
- Enjuagar completamente en agua limpia.
- Envolverlo en un paño limpio y exprimirlo (sin estrujar) hasta que esté completamente seco, o dejar secar al aire.
- Saturar con aceite para motor y exprimirlo para distribuir el aceite y eliminar el aceite sobrante.
- Colocar el filtro de espuma dentro de la caja de plástico.

NOTE: Si el filtro de espuma está desgarrado o tiene cualquier daño, cambiarlo.



ADVERTENCIA: La temperatura del silenciador y las áreas cercanas puede sobrepasar de 150°F (65°C). Evitar tocar esas áreas.

SERVICIO DE LA BUJIA

 Limpiar la bujía y ajustar la distancia entre electrodos a 0.030 pulgada por lo menos una vez en la temporada o cada 50 horas de funcionamiento. Ver la Figura 12. Se recomienda cambiar la bujía al comienzo de cada temporada o estación. Consultar la lista de repuestos del motor para determinar el tipo correcto de bujía.

NOTE: No limpiar la bujía con un chorro de arena. Hacerlo con un cepillo de alambre o una rasqueta y lavarla con un solvente comercial.




Figura 12

SERVICIO DEL SILENCIADOR

- Inspeccionar el silenciador periódicamente y reemplazarlo cuando sea necesario.
- Si el motor tiene un chispero, retirarlo cada 50 horas de uso para limpieza e inspección.
 Reemplazarlo si está dañado.



WARNING: No manejar la aspiradora para jardines sin que tenga instalado el silenciador. No estorbar el sistema de escape. El silenciador o chispero dañado puede crear un peligro de incendio.

LIMPIEZA DEL MOTOR

- Para limpiar el motor, quitarle la tierra y residuos con un paño o cepillo.
- Quitar frecuentemente los restos de pasto, tierra y residuos de las aletas de enfriamiento, tamiz de la toma de aire, palancas y varillaje. Esto ayudará a asegurar el enfriamiento adecuado y la velocidad del motor.

SERVICIO Y AJUSTES



ADVERTENCIA: Nunca hacer ningún ajuste a la máquina sin primero apagar el motor y desconectar el cable de la bujía.

Ajuste de la altura del pico

Puede ajustar el pico en seis posiciones que varían desde 5/8" a 4 1/8" de distancia del suelo. Debe ajustar la altura del pico según las condiciones. Mueva las palancas para ajustar la altura hacia adelante o hacia atrás para ajustar el pico hacia arriba o hacia abajo. Ver Figura 13.




Figura 13

AJUSTE DEL CARBURADOR



ADVERTENCIA: Si al motor se le hace cualquier ajuste (por ej., carburador) mientras está funcionando, mantenerse alejado de todas las piezas en movimiento. Tener cuidado de no tocar el silenciador y todas las superficies calientes.

El carburador fue preajustado en la fábrica y no debería necesitar ningún ajuste. Si el motor no funciona debidamente debido a posibles problemas en el carburador, llevar la máquina a un centro de servicio Sears para reparación y ajuste.

NOTE: El filtro de aire sucio causará el funcionamiento irregular del motor. Asegurarse de limpiar el filtro de aire y que esté conectado al carburador antes de proceder a ajustar el carburador.

VELOCIDAD DEL MOTOR

La velocidad del motor de la aspiradora para jardinesaspiradora para jardines fue ajustada en la fábrica. No intentar aumentar las revoluciones por minuto del motor. En el caso de que el motor esté funcionando demasiado rápido o lento, llevar la

máquina a un centro de servicio Sears para reparación y ajuste.



WARNING: No intentar alterar la velocidad del motor moviendo el varillaje del gobernador del motor. El hacerlo podría resultar en graves lesiones personales y daño al motor. La velocidad (rpm) del motor fue ajustada en la fábrica.

RETIRO DE LA REJILLA DE FLAGELOS

En el caso de que el área de descarga está obstruida, retirar la rejilla de flagelos y limpiar el área de la manera siguiente.

- Apagar el motor. Asegurarse que la máquina está totalmente detenida.
- Desconectar el cable de la bujía y conectarlo a tierra antes de desatascar el tubo de descarga.
- Ver tener acceso a la rejilla de trituración, retirar el recolector o el tubo de soplado de la máquina como se indica en la sección OPERACION. Ver la Figura 14.




Figura 14

 En el lado derecho de la máquina, quitar el tornillo hexagonal que sujeta la rejilla de flagelos.
 Ver la Figura 15.




Figura 15

- Retirar el tornillo hexagonal y la arandela plana ubicados encima de la carcasa trasera cerca de la escuadra de montaje y la contratuerca que sujeta la rejilla de flagelos. Ver las Figura 14.
- Retirar y limpiar la rejilla con una rasqueta o lavarla con agua. Volver a instalar la rejilla.

AFILADO O REEMPLAZO DE LA CUCHILLA ASTILLADORA

Debido a que el motor de esta máquina tiene el cigüeñal cónico, se necesita un extractor especial (número de pieza 753-0900) para retirar el impulsor. Para asistencia técnica, comunicarse con el centro de servicio Sears.

NOTE: Cuando se vaya a inclinar la máquina, vaciar el tanque de combustible y mantener el lado con la bujía del motor hacia arriba.

- Desconectar el cable de la bujía y conectarlo a tierra.
- Quite los tapacuboss delanteros, ciérrese chiflado, ruedas delanteras, y las arandelas de onda(ola) que atan a las asambleas de brazo de pivote. Ver la Figura 16.




Figura 16

- Quite los tornillos de hombro y las arandelas de campana que examinan las armas(brazos) de pivote y ajustadores de anaquel de altura a la abrazadera de apoyo delantera.
- Quitar los tres tornillos en la carcasa superior que sujetan la cubierta de la boquilla y los nueve tornillos que sujetan la carcasa inferior a la superior. Ver la Figura 17.
- Quitar la contratuerca que sujeta la rejilla de trituración a la carcasa inferior. No es necesario retirar la rejilla. Ver las Figura 14.




Figura 17

 Quitar el perno hexagonal, la arandela de seguridad y la arandela plana que sujetan el conjunto rotor al cigüeñal. Ver la Figura 18.




Figura 18

- Aplicar lubricante a las roscas del extractor del rotor y luego enroscar el extractor en el cigüeñal.
 Parar cuando el rotor se pueda mover en el cigüeñal.
- Retirar el rotor del cigüeñal. Desenroscar el extractor del rotor.
- Retirar la cuchilla astilladora utilizando para ello una llave allen de 3/16" en el exterior de la cuchilla y una llave de 1/2" en el lado inferior del rotor.
- Reemplazar o afilar la cuchilla astilladora.
- Para afilar la cuchilla, protegerse las manos con guantes y seguir el ángulo original de afilado.
- Volver a ensamblar ejecutando los pasos previosos en orden inverso.

- Apretar los tornillos de la cuchilla a 210 250 pulg-lbs.
- Apretar el perno del rotor a 375-425 pulg-lbs.

NOTE: Asegurar de instalar la cuchilla astilladora con el filo hacia arriba. Ver la Figura 19.




Figura 19

ALMACENAMIENTO

Preparar la aspiradora para jardines Crafstman para su almacenamiento al final de la temporada o si la máquina va a estar sin usar durante 30 días o más. Una revisión anual por el centro de servicio Sears local es una buena manera de asegurar que la máquina funcione perfectamente la temporada siguiente.

Aspiradora para jardines

- Limpiar el equipo completamente.
- Frotarlo con un trapa aceitado para impedir que se oxide. Frotar con aceite ligero o silicona.
- Preparar el motor de acuerdo a las instrucciones siguientes.
- Guardar la máquina en un lugar limpio y seco. No hacerlo cerca de materiales corrosivos tal como los fertilizantes.

Motor

IMPORTANT: Es importante impedir la formación de depósitos gomosos en las piezas del sistema de combustible tales como el carburador, filtro, manguera y tanque de combustible durante el almacenamiento. Además, los combustibles mezclados con alcohol (llamados gasohol o el uso de etanol o metanol) pueden atraer humedad la que conduce a la separación y formación de ácidos durante el almacenamiento. El gas ácido puede dañar el sistema de combustible del motor durante el almacenamiento.

Para evitar problemas en el motor, vaciar el sistema de combustible antes de guardar la máquina por 30 días o más. Proceder de la manera siguiente:

- Vaciar el tanque de combustible.
- Arrancar el motor y dejarlo funcionar hasta que la tubería de combustible y el carburador estén vacíos.
- Vaciar el carburador.
- Nunca usar productos para limpiar motores o carburadores en el tanque de combustible pues podría ocurrir un daño permanente.

NOTE: El uso de un estabilizador de combustible es una alternativa aceptable para reducir la formación de depósitos gomosos de combustible durante el almacenamiento.

- Añadir estabilizador a la gasolina en el tanque o en el contenedor de almacenamiento.
- Siempre seguir la relación de mezcla indicada en el envase del estabilizador.
- Hacer funcionar el motor durante por lo menos 10 minutos después de añadir el estabilizador para que éste llegue al carburador.
- No vaciar el tanque de combustible y el carburador si se usa estabilizador de combustible. Vaciar el aceite del cárter (hacerlo después de haber hecho funcionar el motor y que todavía esté caliente) y llenar el cárter con aceite fresco.
- Si se vació el tanque de combustible, proteger el interior del motor de la manera siguiente:
- Retirar la bujía, verter aproximadamente 1/2 onza (aprox. una cucharada) de aceite de motor en el cilindro y hacer girar lentamente el motor para distribuir el aceite.
- · Colocar la bujía.

Otros

- No guardar la gasolina de una temporada a otra.
- Reemplazar la gasolina si comienza a oxidarse. El óxido y/o impurezas en la gasolina causarán problemas.
- Guardar la máqina en un lugar limpio y seco. No hacerlo cerca de materiales corrosivos, tal como los fertilizantes.

NOTE: Si se va a guardar la máquina en un galpón sin ventilación o de metal, asegurarse de protegerla contra oxidación aplicándole una capa de aceite ligero o silicona.

LOCALIZACION DE AVERIAS

Problema	Causas posibles			Solución				
El motor no arranca	1.	El tanque de combustible está vacío o combustible está viejo.		Llenar el tanque con gasolina limpia y fresca. El combustible no durará más de treinta días a menos que se le añada un estabilizador.				
	2.	El cable de la bujía está desconectado.	2.	Conectar el cable de la bujía.				
	3.	No se puede tirar de la cuerda de arranque.	3.	Hay una obstrucción atascada en el rotor. Desconectar el cable de la bujía y quitar el objeto atascado.				
	4.	El estrangulador está en la posición ON (conectado).	4.	Mover de la posición CHOKE a la posición ON.				
	5.	La bujía está mala.	5.	Limpiar y ajustar la distancia entre electrodos o cambiar la bujía.				
	6.	No se oprimió el interruptor de seguridad.	6.	El interruptor de seguridad debe estar oprimido por la lengüeta delantera ubicada en el mango del recolector cuando se instala este último.				
	7.	El alambre del interruptor de seguridad no está conectado al motor o está mal conectado a tierra.	7.	seguridad al conector del motor y conectarlo a tierra en la escuadra de montaje.				
Pérdida de potenica; funcionamiento	1. 2.	El cable de la bujía está suelto. La máquina está funcionando	1. 2.	Conectar el cable de la bujía y apretarlo. Mover la palanca de estrangulación a la				
irregular	3.	en CHOKE (estrangulador). La manguera de combustible	3.	posición OFF (desconectado). Limpiar la manguera de combustible; llenar				
	0.	está obstruida o el combustible está viejo.	0.	el tanque con gasolina limpia y fresca. El combustible no durará más de treinta días a menos que se le añada un estabilizador.				
	4.	Hay agua o tierra en el sistema de combustible.	4.	Desconectar la manguera de combustible al carburador y vaciar el tanque. Llenar con combustible fresco.				
	5.	El carburador está desajustado.	5.	Contactar al centro de servicio Sears.				
Demasiada vibración	1.	Piezas sueltas o rotor dañado.	1.	Apagar el motor inmediatamente y desconectar el cable de la bujía. Llevar la máquina a un centro de servicio Sears.				
El motor se sobrecalienta	1. 2.	Carburador mal ajustado. Bajo nivel de aceite del motor.	1. 2.	Conctactar al centro de servicio Sears. Llenar el cárter con el tipo correcto de aceite.				
La máquina no descarga	1.	El tubo de descarga está obturado.	1.	Apagar el motor inmediatamente y desconectar el cable de la bujía. Limpiar la rejilla de trituración y el interior de la boca de descarga. Ver la sección Mantenimiento en este manual.				
	2.	Hay un objeto extraño atascado en el rotor.	2.	Apagar el motor inmediatamente y desconectar el cable de la bujía. Quitar el objeto atascado.				
	3.	Baja velocidad (rpm) del motor.	3.	Siempre hacer funcionar el motor con el acelerador a fondo.				
	4.	El recolector está lleno.	4.	Vaciar el recolector.				
	5.	La cuchilla astilladora está desafilada.		mbiar la cuchilla astilladora o contactar al centro de vicio Sears.				

NOTE: Para otros tipos de reparaciones aparte de los ajustes menores indicados más arriba, rogamos dirigirse al centro de servicio Sears de la localidad.

In U.S.A. or Canada for in-home major brand repair service:

Call 24 hours a day, 7 days a week

1-800-4-MY-HOMESM (1-800-469-4663)

Para pedir servicio de reparación a domicilio – 1-800-676-5811

Au Canada pour tout le service ou les pièces – 1-800-469-4663

For the repair or replacement parts you need:

Call 6 a.m. - 11 p.m. CST, 7 days a week

PartsDirect[™]

1-800-366-PART (1-800-366-7278)

Para ordenar piezas con entrega a domicilio – 1-800-659-7084

For the location of a Sears Service Center in your area:

Call 24 hours a day, 7 days a week

1-800-488-1222

To purchase or inquire about a Sears Maintenance Agreement:

Call 7 a.m. – 5 p.m. CST, Monday – Saturday

1-800-827-6655

